


PROFINET

For RSi “S” & “SW” Series
Variable Frequency Drive
Instruction Manual



890049-11-00

© 2020 Benshaw Inc.

Benshaw retains the right to change specifications and illustrations in text without prior notification. The contents of this document may not be copied without the explicit permission of Benshaw.



BENSHAW
Applied Motor Controls

Safety Information

Carefully read and follow all safety instructions in this manual to avoid unsafe operating conditions, property damage, personal injury, or death. Please keep this manual for future reference.

Safety symbols in this manual

Danger

Indicates an imminently hazardous situation which, if not avoided, could result in severe injury or death.

Warning

Indicates a potentially hazardous situation which, if not avoided, could result in injury or death.

Caution

Indicates a potentially hazardous situation which, if not avoided, could result in minor injury or property damage.

Caution

- ESD (Electrostatic discharge) from the human body may damage sensitive electronic components on the PCB. Therefore, be extremely careful not to touch the PCB or the components on the PCB with bare hands while you work on the I/O PCB.
- Turn off the power to the inverter before making wiring connections. Otherwise, malfunctions including faulty network communication may occur.
- When installing the option board, ensure that the option board is properly connected to the connector on the inverter. Faulty connections may damage the inverter or the option board.
- Check the parameter units before settings the function codes. Wrong units may lead to faulty network communication.

Table of Contents

1	Introduction.....	1
2	Package Components	2
3	Technical Specifications	3
4	Module Layout and Installation	4
4.1	Installation	4
5	Network Cable Specification	7
5.1	Cable Connector.....	7
5.2	Network Cable Specification.....	7
6	Status Diagnosis and LED Indication	8
6.1	LED Display	8
7	Description of Parameters	10
7.1	PROFINET Communication Parameter List	10
7.2	Parameters Descriptions for PROFINET Communication Module	12
8	PROFIdrive Status Diagram.....	15
9	Supported PROFIdrive Cyclic Telegram.....	17
9.1	Standard Telegram (Mode: 0).....	17
9.2	Vendor Specific Telegram (Mode: 1).....	17
10	Supported PROFIdrive Parameters	23
11	Fault Message Counter (PNU[944]) and Fault Number (PNU[947]).....	25
12	Accessing the Common Parameters using the PROFIdrive Parameters ...	28
13	Accessing Inverter Parameters using the PROFINET Record Data Object	30
14	Processing the Alarms.....	31
15	Trouble Shooting	32

1 Introduction

The PROFINET communication module allows the inverter to be connected to a PROFINET network. The PROFINET communication module provides full-duplex data transfer which enables real-time communication without transmission collisions.

- The inverter can be controlled and monitored via a PLC sequence program or any master PLC module.
- PROFINET is a communication protocol compliant with IEC 61158 Type 10.
- PROFINET is easy to connect, enabling faster installation and easier maintenance.

2 Package Components

Benshaw Part # PC-100095-00

The product contains:

1 x PROFINET Communication Module

1 x Brass Standoff (M3xL23)

1 x Brass Standoff (M3xL17.3)

2 x Mounting Screws (M3xL8)


1 x Instrucion Manual

Note: GSDML file for PROFINET required. Download at Benshaw.com. The GSDML file contains information about the PROFINET communication module. When you configure the PROFINET network, the network configuration software requires the GSDML file.

3 Technical Specifications

Item	Description
Communication protocol	PROFINET IO CC-A
Communication speed	100 Mbps
Communication type	Full Duplex
Distance	100m (Twisted Pair)
Max. number of Node	64 ea
Service	PROFIdrive Class 1
Topology	Line, Tree, Star topology

4 Module Layout and Installation




4.1 Installation


Warning

- Do not install or remove the communication module to or from the inverter while the inverter is turned on.
- Ensure that the charge in the capacitors inside the inverter is completely discharged before installing or uninstalling the communication module.
- Connect a communication network after the power supply is off.


- Loosen the front cover screws to remove the front cover (1) and remove I/O cover (2).




- Remove the keypad (3).




- Remove a screw (bottom left) from the I/O board and install the provided brass standoffs (4), longer one at bottom left.




- Mount the PROFINET communication Module (5) and install the removed screw (6) and the supplied screw (7).



- Install the keypad (8) first, then the communication module cover (9).




- Install the front cover (10) and installation is completed.



5 Network Cable Specification

Pin No.	Signal	Description	Cable Color
1	TX+	Data Transmission (+)	White/Yellow
2	TX-	Data Transmission (-)	Yellow
3	RX+	Data Reception (+)	White/Green
4	NONE	Not Used	Blue
5	NONE	Not Used	White/Blue
6	RX-	Data Reception (-)	Green
7	NONE	Not Used	White/Brown
8	NONE	Not Used	Brown

5.1 Cable Connector



** Wires connected to pin #1 and pin #2 must be twisted.

** Wires connected to pin #3 and pin #6 must be twisted.


5.2 Network Cable Specification

PROFINET network communication requires STP (category 6a, or higher) network cables.

6 Status Diagnosis and LED Indication

6.1 LED Display

The PROFINET Module has 4 LED's. Refer to the below tables for indication, trouble shooting and diagnostics.



Indicator	Color	Description	Status	Remarks
CPU	Green	Abnormal operation	OFF	The CPU is not operating.
		Normal operation	Flashing (1 second intervals)	The communication module is installed correctly in the inverter.
ERROR	Red	Normal operation	OFF	Communication between the communication module and the inverter is normal.
		Communication fault	ERROR indicator flashing together with CPU	Communication error occurred between the communication module and the inverter
			ERROR indicator flashes in 2 second intervals, alternating with CPU in 1 second intervals,	Abnormal communication conditions exist between the communication module and the inverter.
			ON	The communication module failed to boot up.
LINK1	Green	Normal operation	ON	LINK1 is connected to a network.
			OFF	LINK1 is not connected to a network

Indicator	Color	Description	Status	Remarks
	Yellow	Normal operation	OFF	Network LINK1 is not transmitting/receiving data
			Flashing	Data transmission between the Master unit and the communication module is in progress at network LINK1.
LINK2	Green	Normal operation	ON	LINK2 is connected to a network.
			OFF	LINK2 is not connected to a network
	Yellow	Normal operation	OFF	Network LINK2 is not transmitting/receiving data
			Flashing	Data transmission between the master unit and the communication module is in progress at network LINK2.

7 Description of Parameters

7.1 PROFINET Communication Parameter List

The following table lists the parameters associated with communications. Detailed parameter descriptions are provided in the following section. Parameters codes are shown for both the LED Display (ex:CM.06) and the LCD display (ex:COM-06).

Code	Parameter Name	Default	Description	
drv dr.06 DRV-06	Cmd Source	1 Fx/Rx-1	0	Keypad
			1	Fx/Rx-1
			2	Fx/Rx-2
			3	Int 485
			4	Fieldbus
			5	UserSeqLink
Frq dr.07 DRV-07	Freq Ref Src	0 Keypad-1	0	Keypad-1
			1	Keypad-2
			2	V1
			4	V2
			5	I2
			6	Int 485
			8	FieldBus
			9	UserSeqLink
			12	Pulse
CM.06 COM-06	FBus S/W Ver	-	Communication module S/W version.	
CM.09 COM-09	FBus Led	-	Shows the ON/OFF status of the LED's on the communication module.	
CM.10 COM-10	10 opt para-1	0	Set up the IP Address.	
CM.11 COM-11	11 opt para-2	0		
CM.12 COM-12	12 opt para-3	0		
CM.13 COM-13	13 opt para-4	0		
CM.14 COM-14	14 opt para-5	0	Set up the Subnet Mask.	
CM.15 COM-15	15 opt para-6	0		

CM.16 COM-16	16 opt para-7	0		
CM.17 COM-17	17 opt para-8	0		
CM.1 COM-18	18 opt para-9	0	Set up the Gateway Address.	
CM.19 COM-19	19 opt para-10	0		
CM.20 COM-20	20 opt para-11	0		
CM.21 COM-21	21 opt para-12	0		
CM.22 COM-22	22 opt para-13	0	Mode (0:STD Telegram1, 1: Vendor Specific Telegram)	
CNF-30	30 Option-1 Type	-	The module type "PROFINET" is automatically detected and displayed.	
CM.94 COM-94	Comm. Update	0	0:NO	Update parameters related to network communications.
			1:YES	
Pr.12 PRT-12	Lost Cmd Source	0 None	0	None
			1	Free-Run
			2	Dec
			3	Hold Input
			4	Hold Output
			5	Lost Preset
Pr.13 PRT-13	Lost Cmd Time	1.0	0.1–120 [s]	
Pr.14 PRT-14	Lost Preset F	0.00	0.50–60.00 [Hz]	

7.2 Parameters Descriptions for PROFINET Communication Module

7.2.1 DRV-06 - Cmd Source

To operate (Start/Stop) the inverter using the PROFINET communication module, set DRV-06 (Cmd Source) to [4 Fieldbus].

7.2.2 DRV-07 - Freq Ref Src

Set DRV-07 (Freq Ref Src) to [8 Fieldbus] to provide a frequency reference to the inverter using the PROFINET communication module.

7.2.3 COM-06 - FBus S/W Ver

Automatically detects and displays the software version of the currently installed communication module.


7.2.4 CM.09, COM-09 - FBus LED, (LED) Information

CM.09 - The LED Display/Keypad displays the ON/OFF state of the 4 communication module LED's at LED keypad parameter CM.09. The display LED segments represent the 4 communication LED's according to:

(Left -> Right) LINK1, LINK2, ERR and CPU.


When the display upper LED segment is on, this designates the communication LED is ON. When the lower LED segment is on, this designates the communication LED is OFF.

Ex: CM.09



COM-09 - The LCD Display/Keypad displays the communication module's status indicator information on the LCD display.

Ex: COM-09 FBus status on the LCD display.




Indicator Name	LINK1/ACT1	LINK2/ACT2	ERR	CPU
Status	OFF	ON	ON	ON

7.2.5 COM-10-21 - IP Address, Subnet Mask, Gateway Settings

The PROFINET communication module supports IPv4 protocol. All addresses and masks are expressed with four decimal numbers between 0 and 255, each separated by a decimal point (xxx.xxx.xxx.xxx). A PLC can forcibly reset the IP address by sending a DCP packet.

For example, when programming a PLC in Siemens TIA, you can select **Set IP address in the project** (1) to allow the PLC to send a DCP packet to a communication module to set an IP address. If you select **IP address is set directly at the device** (2), the PLC reads the IP address set at the communication module and uses it for PROFINET network communication, instead of resetting the IP.



7.2.6 COM-22 - Telegram Mode Settings

The PROFINET Communication module supports two different types of telegrams. Refer to **<9 Supported PROFIdrive Cyclic Telegram>** for the supported telegram types and the details.

Setting	Selected Telegram Type
0	Standard Telegram
1	Vendor Specific Telegram

7.2.7 CNF-30 - Option-1 Type

Automatically detects and displays the type of communication module installed. "PROFINET" is displayed on the LCD Display when a PROFINET communication module is installed in the inverter.

7.2.8 CM.94, COM-94 - Comm Update

Changes made on the keypad are not directly reflected in the communication module. Set CM.94 (Comm Update) to "1 (Yes)". The changed settings will be reflected in the communication module.

7.2.9 PRT-12 - Lost Cmd Mode

When controlling the inverter speed through communications, you can select the inverter response (operating mode) when a network failure occurs (including a connection failure between the inverter and communication). Choices for PRT-12 include Decel, Hold Input, Hold Output or Preset Frequency (Pr.14).

Settings		Description
0	None	Speed reference becomes the operating frequency, without a protective operation.
1	Free-Run	The inverter cuts off the output and the motor free-runs.
2	Dec	The inverter performs a deceleration stop according to the time set at "Trip Dec Time."
3	Hold Input	The inverter keeps operating using the speed reference received before the command loss.
4	Hold Output	The inverter keeps operating using the operation frequency it was operating at before the command loss.
5	Lost Preset	The inverter operates using the frequency reference set at PRT-14 "Lost Preset F."

7.2.10 PRT-13 - Lost Cmd Time


Set the delay time for the inverter to respond to a communications loss. The inverter will operate based on the PRT-12 setting after the delay time set in PRT-13. Delay time can be set between "0.1" and "120" seconds.

7.2.11 PRT-14 - Lost Preset Freq

When the lost command mode (PRT-12) is set to Preset Frequency, set the operating speed for continued inverter operation. The Preset Frequency (PRT-14) can be set between the start frequency and the maximum frequency [Hz].

8 PROFIdrive Status Diagram

The following diagram shows the operation status that the PROFINET communication module uses.



Status	Description
S1: Switching On Inhibited	The communication module cannot be switched ON at the moment.
S2: Ready For Switching On	The communication module can be switched ON at any moment.
S3: Ready For Operation	Communication module operation is ready to be enabled.
S4: Operation enable	The motor is running.

Status transitions are directed by the commands that are periodically transmitted from the PLC and the command types are as follows. Refer to **<9.2.1 Control word (STW1)>** for more information.

- NoQuickStop Command
- NoCoastStop Command
- SwitchOFF Command
- SwitchON Command
- OperationEnable Command
- OperationDisable Command
- QuickStop Command
- CoastStop Command

The following table lists status transition events and the resulting inverter operations:

Source Status	Target Status	Event	Action (Inverter operation)
"Switch On Inhibited"	"Ready For Switching On"	"SwitchOFF" and "NoQuickStop" and "NoCoastStop"	None (Motor is stopped.)
"Ready For Switching On"	"Switch On Inhibited"	"QuickStop" or "CoastStop"	None (Motor is stopped.)
"Ready For Switching On"	"Ready For Operation"	"SwitchON"	None (Motor is stopped.)
"Ready For Operation"	"Ready For Switching On"	"SwitchOFF"	None (Motor is stopped.)
"Ready For Operation"	"Operation"	"OperationEnable"	Motor is run.
"Operation"	"Ready For Operation"	"OperationDisable"	Motor is stopped (the inverter stops the motor according to the ADV-08 "Stop Mode" settings).
"Operation"	"Switch On Inhibited"	"CoastStop"	Motor is stopped (Free Run Stop).
"Operation"	"Switch On Inhibited"	"QuickStop"	Motor is stopped (the inverter stops the motor according to the ADV-08 "Stop Mode" settings).

9 Supported PROFIdrive Cyclic Telegram

The communication module supports “Standard” and “Vendor Specific” telegrams. On a PROFINET network, it can exchange cyclic telegrams with a PLC at a minimum cycle time of 8 ms. Each telegram is expressed as a submodule in PROFINET network communication and can be assigned to either Slot1 or Subslot 2 at the communication module.

9.1 Standard Telegram (Mode: 0)

Standard telegram1	Byte 1-2	Byte 3-4
PLC to inverter	Control word (STW1)	Setpoint value
Inverter to PLC	Status word (ZSW1)	Actual speed value

9.2 Vendor Specific Telegram (Mode: 1)

Vendor Specific telegram1	Byte 1-2	Byte 3-4	Byte 5-6	Byte 7-8	Byte 9-10
PLC to Inverter	Control word (STW1)	Setpoint value	Dummy	Dummy	Dummy
Inverter to PLC	Status word (ZSW1)	Actual speed value	Alarm Info	Torque	Current

The following table lists settings for Standard and Vendor Specific Telegrams.

9.2.1 Control word (STW1)

Bit	Name	Value	Description
0	ON	1	Ready for operation (Operation by a PLC is available.)
	OFF1	0	NOT Ready for operation (Operation by a PLC is not available.)
1	No OFF2	1	OFF2 (Coast Stop) feature is disabled. Current operation is maintained.
	OFF2 (Coast Stop)	0	Stops the motor using a free-run stop (emergency stop).
2	No OFF3	1	OFF3 (Quick Stop) feature is disabled. Current operation is maintained.
	OFF3 (Quick Stop)	0	Stops the motor using the setting at the inverter (ADV-08 “Stop Mode”).
3	Enable Operation	1	Operates the motor using the Setpoint value (frequency reference received from a PLC via the PROFINET network communication).
	Disable Operation	0	Stops the motor using the setting at the inverter (ADV-08 “Stop Mode”).
4	Enable Ramp Generator	1	Performs acceleration and deceleration based on the acceleration and deceleration time settings at inverter (DRV-03, 04) to reach the Setpoint (frequency reference).

Bit	Name	Value	Description
	Reset Ramp Generator	0	Forces the operation frequency to "0." (Operating frequency drops to "0" after decelerating based on the Dec Time set at the inverter).
5	Unfreeze Ramp Generator	1	A fixed Ramp Generator operation is not assigned. Acceleration and deceleration is performed based on the Acc/Dec times configured in the inverter (DRV-03, 04) parameter settings to reach the Setpoint (frequency reference).
	Freeze Ramp Generator	0	Speed reference from the PLC is ignored and the Ramp Generator operation is fixed. The motor is operated via the network communication by the PROFINET and the current operation frequency is maintained.
6	Enable Setpoint	1	The motor is operated based on the speed reference from the PLC.
	Disable Setpoint	0	Forces the motor operation frequency to "0."
7	Fault Acknowledge	(0 -> 1)	Set to 1 to release fault conditions at the inverter.
8	Jog1 ON/OFF	-	Not supported
9	Jog2 ON/OFF	-	Not supported
10	Control By PLC	1	The inverter is controlled by the PLC's control word (STW1) received via the PROFINET network communication.
	No Control By PLC	0	The PLC's control word (STW1) received via the PROFINET network communication is ignored.
11–15	-	-	Reserved

The status transition explained in <8. PROFIdrive Status Diagram> can be performed by setting the four control word bits, from bit 0 to bit 3. For example, setting the four bits to 1 (XXXX XXXX XXXX 1111) changes the status to "Operation."

Note

"X" in the bit setting example indicates that the relevant bit can be set to either 0 or 1 without affecting the control word bit settings.

The following table lists the status transition controlled by the control word bits (Bits 0 to 3).

Command	Bit3	Bit2	Bit1	Bit0
QuickStop	X	0	X	X
CoastStop	X	X	0	X
NoQuickStop	X	1	X	X
NoCoastStop	X	X	1	X
SwitchOFF	X	1	1	0
SwitchON	X	1	1	1

Command	Bit3	Bit2	Bit1	Bit0
OperationEnable	1	1	1	1
OperationDisable	0	1	1	1

Internally, the control uses the inverter's operation command at communication address 0x0382, and the Control word (STW1) for basic motor operation uses address 0x47F (bits 0, 1, 2, 3, 4, 5, 6, 10). When a PLC sets the bits at 0x47F, motor operation is possible simply by providing a frequency reference.

Example) Bit Settings for Motor Operation

Bit	Bit10	Bit9	Bit8	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Setting	1	—Note)	—Note)	0	1	1	1	1	1	1	1

Note) '—' indicates that the bit can be set to either 0 or 1 without affecting the motor operation.

9.2.2 Status Word (ZSW1)

Bit	Name	Value	Description
0	RDY_ON	1	Ready for Switch ON (Operation is available.)
		0	Not Ready for Switch OFF (Operation is not available.)
1	RDY_OPERATION	1	Bit 0 value of the control word (STW1) that has been input.
		0	
2	OPERATION	1	Bit 3 value of the control word (STW1) that has been input.
		0	
3	Fault Present	1	Fault condition is present at the inverter.
	No Fault	0	Fault condition is not present at the inverter.
4	No OFF2	1	Bit 1 value of the control word (STW1) that has been input.
	OFF2	0	
5	No OFF3	1	Bit 2 value of the control word (STW1) that has been input.
	OFF3	0	
6	SWC_ON_INHIB	1	Switching On inhibited (Control is not available.)
		0	Switching On Not inhibited (Control is available.)
7	Warning Present	1	Warning condition is present at the inverter.
	No Warning Present	0	Warning condition is not present at the inverter.
8	Speed Error within tolerance	1	The motor speed has reached the frequency reference ("Setpoint value").
	Speed Error out of tolerance	0	The motor speed has not reached the frequency reference ("Setpoint value").
9	Control Requested	1	Bit 10 value of the control word (STW1) that has been input.
	No Control Requested	0	
10	ABOVE_LIMIT	-	Not supported
11 to 15	-	-	Reserved

"bits 0 to 2" and "bit 6" indicate the following communication module status, as explained in <8. PROFIdrive Status Diagram>.

Status Word	Status
xxxx xxxx x1xx x000	"Switching On Inhibited"
xxxx xxxx x0xx x001	"Ready For Switching On"
xxxx xxxx x0xx x011	"Ready For Operation"
xxxx xxxx x0xx x111	"Operation"

Note

"X" in the bit setting example indicates that the bit can be set to either 0 or 1 without affecting the control word bit settings.

9.2.3 Setpoint value

Frequency reference for inverter operation. Setpoint value is expressed in Hz and can be increased or decreased by 0.01 Hz. If you input (-) value in data, it runs in reverse direction. Ex) SetPoint Value : (5000 -> FWD 50.00Hz), (-5000 -> REV 50.00Hz)

9.2.4 Actual speed value

The inverter's actual output frequency. Actual speed value is expressed in Hz and can be increased or decreased by 0.01 Hz.

9.2.5 Alarm Information

Bit	Name	Description
0	Bit for displaying "latch type trip information-1"	This bit is set to 1 when more than one bit in the "latch type trip information-1" parameter bit field is set to 1. Otherwise, it is set to 0. This bit references address 0h0330 in the inverter's compatible parameter communication addresses.
1	Bit for displaying "latch type trip information-2"	This bit is set to 1 when more than one bit in the "latch type trip information-2" parameter bit field is set to 1. Otherwise, it is set to 0. This bit references address 0h0331 in the inverter's compatible parameter communication addresses.
2	Bit for displaying "level type trip information"	This bit is set to 1 when more than one bit in the "level type trip information" parameter bit field is set to 1. Otherwise, it is set to 0. This bit references address 0h0332 in the inverter's compatible parameter communication addresses.
3	Bit for displaying "H/W Diagnosis Trip information"	This bit is set to 1 when more than one bit in the "H/W Diagnosis Trip information" parameter bit field is set to 1. Otherwise, it is set to 0. This bit references address 0h0333 in the inverter's compatible parameter communication addresses.
4	Bit for displaying "Warning information"	This bit is set to 1 when more than one bit in the "Warning information" parameter bit field is set to 1. Otherwise, it is set to 0. This bit references address 0h0334 in the inverter's compatible parameter communication addresses.
5 to 15	-	Reserved

9.2.6 Torque

The inverter's output torque. Torque is expressed in percentages (%) and can be increased or decreased by 0.1%.

⚠ Caution

Torque value is displayed correctly only if the inverter's control mode is set to "Sensorless".

9.2.7 Current

The inverter's output current. Torque is expressed in amperes (A) and can be increased or decreased by 0.1 A.

10 Supported PROFIdrive Parameters

Parameters

PNU	R/W	Description
922	R	Displays the selected PROFIdrive Cyclic Telegram type. 1 → Standard Telegram 100 → Vendor Specific Telegram * This parameter does not support writing via PROFIdrive protocol. Set this parameter using the inverter keypad. Go to COM-22 "opt para-13," and set it to "0" to select "Standard Telegram," and to "1" to select "Vendor Specific Telegram."
944	R	Fault message counter The parameter value increases by 1 each time a fault condition occurs. The controller, such as a PLC, on the PROFINET is notified of the inverter's fault condition by this parameter.
947	R	Fault number
953	R	Warning word * Displays the "Warning information" parameter value at communication address 0h0334.
964	R	An array of five 16-bit word values that expresses the communication module information. 0: Manufacturer (the PROFINET vendor ID "849" as defined by the Profibus.org, is displayed (referenced from communication address 0h351). 1. Device Type: "1" is displayed for PROFINET communication module. 2. Version: Displays the software version. <i>E.g.,) "102" for Version 1.2</i> 3. Firmware Date (yyyy): Displays the year of the software release. <i>E.g.,) "2015" for the year 2015</i> 4. Firmware Data (dd/mm): Displays the date and month of the software release. <i>E.g.,) "2512" for December 25</i>
965	R	Indicates the Profile ID. (0h328 – Profile 3 v4.0)
967	R	Displays the control word (STW1) value that is currently input via the PROFINET communication network.
968	R	Displays the status word (ZSW1) value that is currently input via the PROFINET communication network.
972	R/W	The communication module is reset when the parameter value is changed to "1" from "0."
61000	R	Displays the device name of the PROFINET communication module.
61001	R	Displays the IP address of the PROFINET communication module.


PNU	R/W	Description
61002	R	Displays the MAC address of the PROFINET communication module.
61003	R	Displays the gateway IP address of the PROFINET communication module.
61004	R	Displays the subnet mask of the PROFINET communication module.
1000	R/W	Parameter Access Address (communication address for reading or writing inverter parameters)
1001	R/W	Parameter Access Data (data value of inverter parameters for reading or writing)
1002	R/W	Parameter Access Command 1: write 2: read
1003	R/W	Parameter Access Acknowledge 0: Not completed 1: OK completed 2: Not OK completed

11 Fault Message Counter (PNU[944]) and Fault Number (PNU[947])

The Fault Message Counter (PNU[944]) parameter value increases by 1 each time an inverter fault occurs and the fault is saved at the Fault Number (PNU[947]) parameter.

The Fault Number (PNU[947]) parameter can save 8 Fault Situations and each Fault Situation contains 8 Fault Messages. A Fault Message consists of one 16bit word and the Fault Number (PNU[947]) parameter consists a total of 64 words.

See the following diagram for the basic operation.



In the diagram, the current Fault Message is saved at Fault Situation #1. Each fault message is saved based on the time of occurrence, from index 0 to 63.

The fault messages are written (overwritten) to the memory when every eighth fault message in each Fault Situation is saved at index 7, 15, 23, 31, 39, 47, 55, and 63. When the PLC's control word bit 7 is set to 1, a "Fault Ack" is triggered, which in turn increases the Fault Situation number by 1 until it becomes 7 (Fault Situation #7).

The saved Fault Messages match the inverter trip information (latch type trip info-1, latch type trip info-2, level type trip info, H/W Diagnosis Trip info) as defined in the following table.

Trip Names	Fault Message
Overload Trip	1
Underload Trip	2
Inverter Overload Trip	3
E-Thermal Trip	4


Trip Names	Fault Message
Ground Fault Trip	5
Missing Output Phase Trip	6
Missing Input Phase Trip	7
Reserved	8
Reserved	9
NTC Trip	10
Overcurrent Trip	11
Overvoltage Trip	12
External Trip	13
Arm Short	14
Overheat Trip	15
Fuse Open Trip	16
MC Fail Trip	17
Reserved	18
PTC (Thermal sensor) Trip	19
FAN Trip	20
Reserved	21
Parameter Write Error	22
Pre PID Fail	23
IO Board Connection Fault	24
External Brake Trip	25
No Motor Trip	26
Option Card Connection Fault	27
Reserved	28
Safety A Trip	29
Safety B Trip	30
Reserved	31
Reserved	32
BX	33
LV	34
Lost Command	35
Keypad Lost Command	36
Reserved	37
Reserved	38
Reserved	39
Reserved	40

Trip Names	Fault Message
Reserved	41
Reserved	42
Reserved	43
Reserved	44
Reserved	45
Reserved	46
Reserved	47
Reserved	48
ADC Error	49
EEPROM Error	50
Watchdog-1 Error	51
Watchdog-2 Error	52
Reserved	53
QueueFull	54
Reserved	55
Reserved	56
Reserved	57
Reserved	58
Reserved	59
Reserved	60
Reserved	61
Reserved	62
Reserved	63
Internal Communication Error between the Inverter and the Option Card	64

12 Accessing the Common Parameters using the PROFIdrive Parameters


Using the PROFIdrive parameters (PNU [1000–1003]), you can access the inverter parameters for data reading and writing.

The following diagram explains the parameter writing procedure.



- 1 Inverter communication address is assigned to PNU [1000].
- 2 Inverter setting data is assigned to PNU [1001].
- 3 PNU [1003] is set to 0.
- 4 When PNU [1002] is set to 1, the PROFINET communication module references the values assigned at PNU [1000] and PNU [1001] and writes the values to the inverter's internal parameters.
- 5 After writing the inverter's internal parameters, the PROFINET communication module saves the result to PNU [1003].
- 6 PNU [1003] is used to verify successful completion of writing procedure.

The following diagram explains the parameter reading procedure.



- 1 Inverter communication address is assigned to PNU [1000].
- 2 PNU [1003] is set to 0.
- 3 When PNU [1002] is set to 2, the PROFINET communication module references PNU [1000] and reads the data saved in the inverter's internal address pointed by it.
- 4 After reading the inverter's internal parameters, the PROFINET communication module saves the result to PNU [1003]. If the reading procedure is successful, it saves the read data to PNU[1001].
- 5 PNU [1003] is used to verify successful completion of reading procedure. If the reading procedure is successful, the PLC reads the data saved at PNU[1001].

13 Accessing Inverter Parameters using the PROFINET Record Data Object

Using the PROFINET Record Data object, you can access the inverter parameters for data reading and writing without the PROFIdrive communication protocol.

The inverter's parameter data is assigned to the PROFINET Record Data from the index address 0h5000. Using the PROFINET IO RW service, you can directly access the addresses to perform reading and writing.

For example, Siemens PLC users may access the inverter's parameter data mapped to the PROFINET Record using "WRREC" and "RDREC" function blocks. Refer to the user's manual that is supplied with the inverter for more information about the inverter parameter data.

E.g.) The inverter's common parameter address 0h0001 is assigned to a PROFINET index address 0h5001.

14 Processing the Alarms

The communication module sends a PROFINET alarm notification to the PLC when a fault occurs or when it is reset.

Fault Alarm Packet Details

Type	API	Slot Number	Subslot Number	Alarm Specifier	User Structure Identifier	Channel Properties	Channel Error Type
Fault Occurrence	0h3A00	1	2	Diagnosis	0h8000	0h0800	9012
Fault Reset	0h3A00	1	2	Diagnosis	0h8000	0h1000	9012

After a fault alarm is received, the PLC has to read the inverter trip parameters to collect detailed information about the fault, such as the fault type (latch type trip-1, latch type trip-2, level type trip, or H/W diagnosis trip).

15 Trouble Shooting

No.	Symptoms	Resolution
1	ERROR indicator and CPU indicator are both turned off.	<p>Power is not supplied to the communication module.</p> <ul style="list-style-type: none"> • Correctly Install the communication module to the inverter. • Check the connector pins on the communication module for bends or other defects. • If the problem persists after taking the measures listed above, it may indicate that the hardware is malfunctioning.
2	ERROR indicator is turned on, and CPU indicator is turned off.	The hardware is malfunctioning.
3	ERROR indicator and CPU indicator are flashing synchronously in 1 second intervals.	<ul style="list-style-type: none"> • Check the connector pins on the communication module for bends or other defects. • If the problem persists after taking the measures listed above, it may indicate that the hardware is malfunctioning.
4	CPU indicator is flashing in 1 second intervals, and ERROR indicator is flashing in 2 second intervals.	<ul style="list-style-type: none"> • Check the communication link where the LAN cable is connected and ensure that the LINK indicator is turned on. If the LINK indicator is turned off, check the LAN cable and ensure that it is properly connected to the link port. • Check to ensure that the communication module's device name and [COM-22] Telegram Mode parameter settings match the network configuration at the PLC. • Check to ensure that the IP address assigned to the communication module is not already used by other devices on the same network. • If the problem persists after taking the measures listed above, it may indicate that the hardware is malfunctioning.
5	The communication module's IP address is randomly changed.	<ul style="list-style-type: none"> • A PLC can forcibly change the communication module's IP address based on the PLC settings. Check the PLC configuration software and see if the IP change by the PLC is allowed. • Set the PLC software to use the IP address set at the communication module if you do not want the communication module IP to be changed.

Revision History

No	Date	Edition	Changes
1	2016.01	First Release	



BENSHAW
Applied Motor Controls

BENSHAW
615 Alpha Drive
Pittsburgh, PA 15238
Phone: (412) 968-0100
Fax: (412) 968-5415

BENSHAW Canada 550 Bright
Street
Listowel, Ontario N4W 3W3
Phone: (519) 291-5112
Fax: (519) 291-2595