

Ethernet/IP & Modbus-TCP

For RSi H2 Series
Variable Frequency Drive
Instruction Manual



890053-03-01

© 2022 Benshaw Inc.

Benshaw retains the right to change specifications and illustrations in text without prior notification. The contents of this document may not be copied without the explicit permission of Benshaw.



BENSHAW
Applied Motor Controls

Safety Information

- Always follow safety instructions to prevent accidents and potentially hazardous situations.
- Safety precautions are classified into “WARNING” and “CAUTION,” and their meanings are as follows:

Warning

Indicates a potentially hazardous situation which, if not avoided, may cause death or serious injury.

Caution

Indicates a potentially hazardous situation, which, if not avoided, may cause minor injury or damage to the product.

- Symbols used in this document and on the product indicate the following.

Read and follow the instructions carefully to avoid dangerous situations.

 Presence of "dangerous voltage" inside the product that may cause harm or electric shock.

- Keep the operating instructions handy for quick reference.
- Read the operating instructions carefully to fully understand the functions of the H2 series inverters and use them properly.

Caution

- **Be careful not to damage the CMOS elements on the communication board.**
Static charge may cause malfunctioning of the product.
- **Turn off the inverter before connecting communication cables.**
Otherwise, the module may be damaged or a communication error may result.
- **Correctly align the communication board to the installation connector for installation and ensure that it is firmly connected to the inverter.**
Otherwise, the module may be damaged or a communication error may result.
- **Check the parameter units when configuring the parameter values.**
Otherwise, a communication error may occur.

Table of Contents

Table of Contents

| | |
|---|-----------|
| 1 Overview | 1 |
| 2 Technical Specifications | 2 |
| 3 Package Components..... | 2 |
| 4 Board Layout and Installation..... | 3 |
| 4.1 Layout | 3 |
| 4.2 Installation..... | 3 |
| 5 Network Connection | 6 |
| 5.1 Cable Wiring | 6 |
| 5.2 Cable Connector..... | 6 |
| 6 Network Cable Specifications..... | 7 |
| 6.1 Frequency Band | 7 |
| 6.2 Twisted Pair Cable Types..... | 7 |
| 7 Inverter Communication Addresses | 8 |
| 8 Keypad Parameters..... | 9 |
| 9 Description of Keypad Parameters | 12 |
| 9.1 Description of Keypad Parameters (simplified) | 12 |
| 9.2 Configuration Group (CNF)..... | 14 |
| 9.3 DRV Group | 14 |
| 9.4 COM Group..... | 14 |
| 9.5 PRT Group (Lost Command)..... | 19 |

Table of Contents

| | |
|--|-----------|
| 10 Connecting with Other Products | 20 |
| 10.1 Introduction | 20 |
| 10.2 EtherNet/IP | 20 |
| 10.2.1 Basic Protocol Structure | 20 |
| 10.2.2 Implicit Message | 21 |
| 10.2.3 Explicit Messages | 27 |
| 10.2.4 Supported Objects | 28 |
| 10.3 Modbus TCP Frame | 35 |
| 10.3.1 Modbus TCP Frame Structure | 35 |
| 10.3.2 Function Codes | 36 |
| 10.3.3 Exception (Except) Frame | 39 |
| 10.4 LED Indications and Troubleshooting | 40 |
| 11 Revision History | 41 |

1 Overview

The Ethernet/IP & Modbus-TCP communication board allows the H2 inverter to be connected to an EtherNet network that is compliant with international standards*. The communication board supports two protocols: EtherNet/IP or Modbus TCP.

By utilizing the 100 Mbps auto negotiation feature, the communication board provides real-time network communication without collisions and allows for controlling and monitoring of the inverter via PLC sequence programs or a Modbus master module.

Compatible with H2 inverter S/W version 201.00 (parameter CNF-10).

Compatible with H2P inverter S/W version 202.00 (parameter CNF-10).

With simple network cable wiring, installation times can be reduced and maintenance becomes easier.

*Ref.: IEC 61158 Type 21 , and IEC 62439, RRP.

2 Technical Specifications

| Items | Description | |
|-------------------------|-------------------------|---------------|
| Communication Protocol | EtherNet/IP, Modbus TCP | |
| Communication speed | 100Mbps | |
| Communication type | Auto negotiation | |
| Communication range | 100 m (twisted pair) | |
| Service | Smart scaling | Up to 8 words |
| Max. number of stations | 64 stations | |
| Topology | Line/Ring topology | |
| Communication range | 100 m (twisted pair) | |
| Recommended cable | UTP, FTP, STP | |

3 Package Components

Benshaw Part #: PC-100098-00


The product package contains:

- 1 x Communication board
- 2 x Mounting screws
- 1 x Cable clamp with (2) screws
- 1 x Communication board Instruction Manual.

Note: EDS file for Ethernet required. Download at Benshaw.com.


4 Board Layout and Installation

4.1 Layout



4.2 Installation


- ① Turn off power to the H2 inverter and after the inverter is completely discharged, loosen the front cover screws and remove the front cover.



1 HP - 40 HP (0.75–30 kW)

50 HP - 125 HP (37–90 kW)


- ② Remove the keypad from the inverter.



1 HP - 40 HP (0.75–30 kW)

50 HP - 125 HP (37–90 kW)


- ③ Loosen the top cover screws and remove it.



1 HP - 40 HP (0.75–30 kW)

50 HP - 125 HP (37–90 kW)

- ④ Install the H2 communication board to the right side of the control board engaging the connector. Install screws (M3) in two places.



- ⑤ Assemble the top cover, keypad, and front cover in reverse order of disassembly.

* The installation method is the same for larger inverters (≥ 150 HP, 110kW). Refer to the H2 Instruction Manual for cover identification and removal.

⚠ Warning


- Do not install or remove the communication board to or from the H2 inverter while the inverter is turned on.
- Ensure that the charge in the capacitors inside the inverter is completely discharged before installing or uninstalling the communication board.

5 Network Connection

5.1 Cable Wiring

| Pin no. | Signal | Description | Cable color |
|---------|--------|-----------------------|--------------|
| 1 | TX+ | Data transmission (+) | White/Yellow |
| 2 | TX- | Data transmission (-) | Yellow |
| 3 | RX+ | Data reception (+) | White/Green |
| 4 | NONE | Not used | Blue |
| 5 | NONE | Not used | White/Blue |
| 6 | RX- | Data reception (-) | Green |
| 7 | NONE | Not used | White/Brown |
| 8 | NONE | Not used | Brown |

5.2 Cable Connector



** The cables connected to pin 1 and pin 2 must be twisted in a pair.

** The cables connected to pin 3 and pin 6 must be twisted in a pair.


6 Network Cable Specifications

6.1 Frequency Band


There are five types of UTP cable specifications according to different applications, from category 1 through category 5. Category 5 network cables are required for utilizing the communication board.

Category 5 network cables support a frequency band up to 100 MHz, with up to 60 MHz channel performance and up to 100 Mbps data transmission speed.


6.2 Twisted Pair Cable Types



UTP



FTP



STP

| Category | Description | Specifications/Usage |
|----------------|---|---|
| UTP (U.UTP) | Unshielded Twisted Pair cable for high speed signals | 200 MHz max. Voice + Data + Low quality video signals |
| FTP (S.UTP) | Single insulation for the cable core * Insulation material: AL / Plastic complex foil or copper braid | 100 MHz max. Protection against EMI, electrically stable Voice + Data + Low quality video signals |
| STP (S.STP) | Dual insulation for the pair and the cable core * Material for cable pair insulation: AL/Plastic complex foil * Material for cable core insulation: AL / Plastic complex foil or copper braid | 500MHz max. Voice + Data + Video signals Replaces 75Ω coaxial cable |

7 Inverter Communication Addresses

Refer to “Chapter 7, RS-485 Communication Features” and “Chapter 8, Table of Functions” of the “H2 Instruction Manual”, 890053-00-00 for details.

8 Keypad Parameters

The following table lists the inverter parameters related to EtherNet/IP and Modbus-TCP communication features. Application types for each parameter is specified in the “Protocol” column: E (EtherNet/IP) or M (Modbus TCP).

Setting Start/Stop: Using the keypad, set DRV-06 parameter (Cmd Source) to “4 (Field Bus)” if you want to operate (start/stop) the H2 inverter via communications.

Setting Frequency Reference: Using the keypad, set DRV-07 parameter (Frq Ref Src) to “7 (Field bBus)” if you want to provide the frequency reference via communications.

| Keypad parameters related to H2 communication board | | | | | |
|---|------------------|---------------|---------|--|----------|
| Code No. | Parameter Name | Initial Value | Range | Description | Protocol |
| CNF-30 | Option-1 Type | - | - | Displays the name of the installed option board. (Depending on the inverter OS version, it may be displayed as Reserved-18 instead of by name.) | E/M |
| DRV-06 | Cmd Source | 1 | 0 – 5 | 4: Set to “Field Bus.” | E/M |
| DRV-07 | Freq Ref Src | 0 | 0 – 11 | 7: Set to “Field Bus.” | E/M |
| COM-06 | FBus S/W Ver | - | - | Indicates the version of the installed option board. | E/M |
| COM-07 | FBus ID | 10 | 0 – 255 | Set the station number of the communication board. | E |
| COM-09 | FBus Led | | | Displays the on/off status of the LED indicators on the communication board. | E/M |
| COM-10 | Opt Parameter1 | 192 | 0 – 255 | Sets the IP address. | E/M |
| COM-11 | Opt Parameter2 | 168 | 0 – 255 | | |
| COM-12 | Opt Parameter3 | 1 | 0 – 255 | | |
| COM-13 | Opt Parameter4 | 101 | 0 – 255 | | |
| COM-14 | Opt Parameter5 | 255 | 0 – 255 | Set the subnet mask. | E/M |
| COM-15 | Opt Parameter6 | 255 | 0 – 255 | | |
| COM-16 | Opt Parameter7 | 255 | 0 – 255 | | |
| COM-17 | Opt Parameter8 | 0 | 0 – 255 | | |
| COM-18 | Opt Parameter9 | 192 | 0 – 255 | Sets the Gateway address. | E/M |
| COM-19 | Opt Parameter 10 | 168 | 0 – 255 | | |
| COM-20 | Opt Parameter 11 | 1 | 0 – 255 | | |
| COM-21 | Opt Parameter 12 | 10 | 0 – 255 | | |

| Keypad parameters related to H2 communication board | | | | | |
|---|------------------|---|--------|---|-----|
| COM-22 | Opt Parameter 13 | 0 | 0 | Set the network communication speed. (fixed to 100 Mbps Auto) | E/M |
| COM-23 | Opt Parameter 14 | 1 | 0 – 11 | CIP Input Instance | E/M |
| COM-24 | Opt Parameter 15 | 1 | 0 – 11 | CIP Output Instance | E/M |

Ref.

After making changes to parameter COM-07 and parameters COM-10 – 24, you must set COM-94 (Comm-Update) to “1 (Yes)” to save the changes. If COM-94 [Comm-Update] has not been set after making the parameter changes, the LED indicator will flash in red at 2-second intervals to warn the user.

| Keypad parameters related to H2 communication board | | | | | |
|---|-----------------|---------------|----------------|--|----------|
| Code No. | Parameter Name | Initial Value | Range | Description | Protocol |
| COM-30 | Para Status Num | 3 | 0 – 8 | Automatically set according to the CIP Input Instance. | E/M |
| COM-31 | Para Status-1 | 000A | 0x0000 -0xFFFF | Set up the inverter address to be read by the client. (Hex.) | E/M |
| COM-32 | Para Status-2 | 000E | 0x0000 -0xFFFF | Set up the inverter address to be read by the client. (Hex.) | E/M |
| COM-33 | Para Status-3 | 000F | 0x0000 -0xFFFF | Set up the inverter address to be read by the client. (Hex.) | E/M |
| COM-34 | Para Status-4 | - | 0x0000 -0xFFFF | Set up the inverter address to be read by the client. (Hex.) | E/M |
| COM-35 | Para Status-5 | - | 0x0000 -0xFFFF | Set up the inverter address to be read by the client. (Hex.) | E/M |
| COM-36 | Para Status-6 | - | 0x0000 -0xFFFF | Set up the inverter address to be read by the client. (Hex.) | E/M |
| COM-37 | Para Status-7 | - | 0x0000 -0xFFFF | Set up the inverter address to be read by the client. (Hex.) | E/M |
| COM-38 | Para Status-8 | - | 0x0000 -0xFFFF | Set up the inverter address to be read by the client. (Hex.) | E/M |
| COM-50 | Para Ctrl Num | 2 | 0 – 8 | Automatically set according to the CIP Output Instance. | E/M |
| COM-51 | Para Control-1 | 0005 | 0x0000 | Sets up the client's command | E/M |

| Keypad parameters related to H2 communication board | | | | | |
|---|----------------|------|---|--|-----|
| | | | -0xFFFF | address. (Hex.) | |
| COM-52 | Para Control-2 | 0006 | 0x0000 -0xFFFF | Sets up the client's command address. (Hex.) | E/M |
| COM-53 | Para Control-3 | - | 0x0000 -0xFFFF | Sets up the client's command address. (Hex.) | E/M |
| COM-54 | Para Control-4 | - | 0x0000 -0xFFFF | Sets up the client's command address. (Hex.) | E/M |
| COM-55 | Para Control-5 | - | 0x0000 -0xFFFF | Sets up the client's command address. (Hex.) | E/M |
| COM-56 | Para Control-6 | - | 0x0000 -0xFFFF | Sets up the client's command address. (Hex.) | E/M |
| COM-57 | Para Control-7 | - | 0x0000 -0xFFFF | Sets up the client's command address. (Hex.) | E/M |
| COM-58 | Para Control-8 | - | 0x0000 -0xFFFF | Sets up the client's command address. (Hex.) | E/M |
| COM-94 | Comm Update | 0 | 0: NO 1: YES | Update keypad parameters related to network communication. | E/M |
| PRT-12 <small>Note 1</small> | Lost Cmd Mode | None | 0: None 1: Free-Run 2: Dec 3: Hold Input 4: Hold Output 5: Lost Preset | Set the inverter operation for when a Lost Command has occurred. (Note1) | E/M |
| PRT-13 | Lost Cmd Time | 1.0 | 0.1 – 120 | Lost Command trigger time | E/M |
| PRT-14 | Lost Preset F | 0.00 | 0.05 – 60.00 | Sets the Lost Preset speed | E/M |

Note 1: PRT-12, Lost Command Mode

| Set value | Function |
|---------------|---|
| "None" | Maintains the previous status. |
| "Free-Run" | Lost Command Trip occurs and a free run stop is made. |
| "Dec" | Lost Command Trip occurs and a deceleration stop is made. |
| "Hold Input" | Lost Command Warning occurs and the inverter operates with the previous speed reference. |
| "Hold Output" | Lost Command Warning occurs and the inverter operates with the previous running speed. |
| "Lost Preset" | Lost Command Warning occurs and the inverter operates with speed reference set at PRT-14. |

9 Description of Keypad Parameters

9.1 Description of Keypad Parameters (simplified)

The following table lists the simplified information of keypad parameters. The detailed information is provided in the following sections (9.2 ~ 9.5, Groups section).

| Code | Parameter Name | Description |
|------|-------------------|---|
| CNF | 30 Option-1 Type | Displays the option slot-1 type |
| DRV | 06 Cmd Source | Command Source |
| | 07 Freq Ref Src | Frequency reference source |
| COM | 06 FBUS S/W Ver | Communication option S/W version |
| | 07 FBUS ID | Station ID of the communication board (communication board ID) |
| | 09 FBUS Led | Information about LED indicators on the communication board |
| | 10 opt para-1 | Enter the 1st decimal number of the IP address. |
| | 11 opt para-2 | Enter the 2nd decimal number of the IP address. |
| | 12 opt para-3 | Enter the 3rd decimal number of the IP address. |
| | 13 opt para-4 | Enter the 4th decimal number of the IP address. |
| | 14 opt para-5 | Enter the 1st decimal number of the subnet address. |
| | 15 opt para-6 | Enter the 2nd decimal number of the subnet address. |
| | 16 opt para-7 | Enter the 3rd decimal number of the subnet address. |
| | 17 opt para-8 | Enter the 4th decimal number of the subnet address. |
| | 18 opt para-9 | Enter the 1st decimal number of the gateway address. |
| | 19 opt para-10 | Enter the 2nd decimal number of the gateway address. |
| | 20 opt para-11 | Enter the 3rd decimal number of the gateway address. |
| | 21 opt para-12 | Enter the 4th decimal number of the gateway address. |
| | 22 opt para-13 | Network communication speed (0 fixed, automatically set to 100 Mbps) |
| | 23 opt para-14 | EtherNet/IP: Set the Input Instance |
| | 24 opt para-15 | EtherNet/IP: Set Output Instance |
| | 30 ParaStatus Num | Displays the number of transmitted data |
| | 31 Para Status-1 | Set address 1 for storing the transmitted data. |

| Code | Parameter Name | Description |
|------|-------------------|---|
| | 32 Para Status-2 | Set address 2 for storing the transmitted data. |
| | 33 Para Status-3 | Set address 3 for storing the transmitted data. |
| | 34 Para Status-4 | Set address 4 for storing the transmitted data. |
| | 35 Para Status-5 | Set address 5 for storing the transmitted data. |
| | 36 Para Status-6 | Set address 6 for storing the transmitted data. |
| | 37 Para Status-7 | Set address 7 for storing the transmitted data. |
| | 38 Para Status-8 | Set address 8 for storing the transmitted data. |
| | 50 Para Ctrl Num | Displays the number of received data |
| | 51 Para Control-1 | Set address 1 for storing the received data. |
| | 52 Para Control-2 | Set address 2 for storing the received data. |
| | 53 Para Control-3 | Set address 3 for storing the received data. |
| | 54 Para Control-4 | Set address 4 for storing the received data. |
| | 55 Para Control-5 | Set address 5 for storing the received data. |
| | 56 Para Control-6 | Set address 6 for storing the received data. |
| | 57 Para Control-7 | Set address 7 for storing the received data. |
| | 58 Para Control-8 | Set address 8 for storing the received data. |
| | 94 Comm Update | Reflect the network parameter changes. |
| PRT | 12 Lost Cmd Mode | Select operation mode for a lost command. |
| | 13 Lost Cmd Time | Set the decision time for a lost command. |
| | 14 Lost Preset F | Set the start frequency for a lost command. |

9.2 Configuration Group (CNF)

① [CNF-30] Option-1 Type: Display the type of option slot 1

It automatically displays the type of communication option board currently installed in H2. When the communication option board is mounted in the H2 inverter, it is automatically displayed as name of the option board.

** Depending on the inverter version, it may be displayed as "Reserved-18" instead of by name.

9.3 DRV Group

① [DRV-06] Cmd Source: Command Source

Select the command source for the H2 inverter. Set to "4 (Field Bus)" to set the communication board as the command source and provide commands via network.

② [DRV-07] Freq Ref Src: Frequency reference source

Select the frequency reference source for the H2 inverter. Set to "7 (Field Bus)" to set the communication board as the frequency reference source and provide the frequency reference via network.

9.4 COM Group

① [COM-06] FBus S/W Ver: Communication option S/W version

Automatically indicates the version of the communication board installed to the H2 inverter.

② [COM-07] FBus ID: Station ID of the communication board (communication board ID)


Set the station ID for the H2 communication board. A total of 255 station IDs are available from 0 to 255. (The station ID must be set before you can configure network communication using the protocol.)

When setting the station ID, be careful not to use a station ID that is not already occupied by the PLC system or other network devices.


After making setting changes, you must set COM-94 (Comm Update) to "1 (Yes)" before the changes can take effect.

③ [COM-09] FBus Led: Information about LED indicators on the communication board

Displays on the Keypad the status of the LED indicators on the H2 communication board. Refer to section "10.4 LED indications and troubleshooting."



Example of COM-09 (FBus LED) indication



④ [COM-22] opt para-13: Set the network communication speed. (100 Mbps, Auto Negotiation)

The EtherNet speed parameter is fixed at "0" by default for 100 Mbps communication speed.

⑤ [COM-23] opt para-14: CIP Input Instance - Transmission Data Setting

This parameter is required for EtherNet/IP protocol service. It specifies the data format of the inverter status to be transmitted to the client (originator) during an I/O communication via a CIP (Common Industrial Protocol). Refer to the Assembly Object section of EtherNet/IP.

Select one of the data transmission addresses from COM-31 to COM-38 for monitoring.

You can set "opt para-14 to between "0" and "11." Refer to the following table for the description of the "opt para-14" settings.

| Set value | Input instance value | Data size | Number of parameters |
|-----------|----------------------|-----------|----------------------|
| 0 | 70 | 4 | X |
| 1 | 71 | 4 | X |
| 2 | 110 | 4 | X |
| 3 | 111 | 4 | X |
| 4 | 141 | 2 | 1 |
| 5 | 142 | 4 | 2 |
| 6 | 143 | 6 | 3 |
| 7 | 144 | 8 | 4 |
| 8 | 145 | 10 | 5 |
| 9 | 146 | 12 | 6 |
| 10 | 147 | 14 | 7 |
| 11 | 148 | 16 | 8 |

⑥ [COM-24] opt para-15: CIP Output Instance - Reception Data Setting

This parameter is required for EtherNet/IP protocol service. It configures the format of the command data received by the inverter from the client (originator) during the I/O communication via the CIP (Common Industrial Protocol). Refer to the Assembly Object section of EtherNet/IP.

Select one of the data reception addresses from COM-51 to COM-58 for monitoring.

You can set “opt para-15” to between “0” and “11.” The description of the “opt para-15” settings are as follows.

| Set value | Output instance value | Data size | Number of parameters |
|-----------|-----------------------|-----------|----------------------|
| 0 | 20 | 4 | X |
| 1 | 21 | 4 | X |
| 2 | 100 | 4 | X |
| 3 | 101 | 4 | X |
| 4 | 121 | 2 | 1 |
| 5 | 122 | 4 | 2 |
| 6 | 123 | 6 | 3 |
| 7 | 124 | 8 | 4 |
| 8 | 125 | 10 | 5 |
| 9 | 126 | 12 | 6 |
| 10 | 127 | 14 | 7 |
| 11 | 128 | 16 | 8 |

⑦ [COM-30] ParaStatus Num: Number of transmission data

You can set COM-23 (opt para-14) to change the number of transmission data to between "0" and "8". The communication board can transmit up to 8 pieces of data. You can configure the address of the transmission data with parameters COM-31 through COM-38.

COM-30 Displayed only when Comm Update (COM-94:Yes) is performed after setting the opt para-14 value to 4 or more.

⑧ [COM-31] Para Status1 – [COM38] Para Status8: Transmission data address settings

After setting the number of transmission data with COM-23, enter the matching number of data addresses for the data to transmit to the client (originator) with parameters COM-31 through COM-38.

This parameter setting is not required for Modbus TCP network communications.

⑨ [CM-50] Para Ctrl Num: Number of Reception data

You can set COM-24 (opt para-15) to change the number of reception data to between "0" and "8". The communication board can receive up to 8 pieces of data. You can configure the address for the received data with parameters COM-51 through COM-58.

COM-50 Displayed only when Comm Update (COM-94:Yes) is performed after setting COM-24 (opt para-15) value to 4 or more.

⑩ [COM-51] Para Control1 – [COM58] Para Control8: Reception data address settings

After setting the number of reception data with COM-24, enter the matching number of data addresses for receiving command data from the client (originator) with parameters COM-51 through COM-58.

This parameter setting is not required for Modbus TCP network communications.

⑪ [COM-94] Comm Update: Update setting changes via the communication board

The CM group parameters display the settings stored on the inverter connected to the communication board and the changes made on the keypad are not directly reflected on the communication board.

Set COM-94 (Comm Update) to “1 (Yes)”. The changed settings will be reflected on the communication board. Parameters that require communication updates include CM-07 and CM-10 through COM-24.

9.5 PRT Group (Lost Command)

① [PRT-12] Lost Cmd Mode

When controlling the inverter speed through communications, you can select the inverter response (operating mode) when a network failure occurs (including a connection failure between the inverter and communication). Choices for PRT-12 include Decel, Hold Input, Hold Output or Preset Frequency (PRT-14).

② [PRT-13] Lost Cmd Time

Set the delay time for the inverter to respond to a speed reference loss. The inverter will operate based on the PRT-12 setting after the delay time set in PRT-13. Delay time can be set between "0.1" and "120" seconds.

③ [PRT-14] Lost Preset Frequency

When the lost command mode (PRT-12) is set to Preset Frequency, set the operating speed for continued inverter operation. The Preset Frequency can be set between the start frequency and the max frequency [Hz].

④ Lost command conditions by protocol

- EtherNet/IP

If the implicit message connection (Class 1 Connection) between the originator (a PLC or client) and the target (inverter) breaks for longer than one second, the EtherNet communication board enters lost command mode and the inverter will operate according to the settings at PRT-12 after the time set with PRT-13 has elapsed.

- Modbus TCP

If the Modbus TCP receives no data from the client for five seconds, the EtherNet communication board enters lost command mode and the inverter will operate according to the settings at PRT-12 after the time set with PRT-13 has elapsed.


10 Connecting with Other Products

10.1 Introduction

This chapter explains the services utilizing EtherNet/IP and Modbus TCP protocols when the communication board is connected with other manufacturer's products.

10.2 EtherNet/IP

10.2.1 Basic Protocol Structure



The EtherNet/IP is a protocol which implements the CIP (Common Industrial Protocol, specified by the ODVA) using the TCP and UDP protocols.

Originator: Devices that make connection requests, which are also called clients. PLCs or scanners are examples of originators.

Target: Devices that respond to connection requests, which are also called servers. Inverters are examples of targets.

10.2.2 Implicit Message

Implicit messages are also called I/O messages. It refers to the data communicated between the client (originator) and the server (target) at predefined intervals, via input and output instances.

The class 1 connection is used for implicit messages.

① Scope of support

Transport type

Originator->Target: Point to Point

Target->Originator: Multicast

Transport trigger: Cyclic

Configuration connection: 1

Connection tag: Not available

Priority

Originator->Target: Scheduled

Target->Originator: Scheduled

Configuration data: Not available

② Input instances

Input instances refer to the status data periodically sent from the inverter to PLC or other client devices.

| Instance | Byte | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|----------|------|---|--------------------|---------------------|-------|-----------------------|-----------------------|---------|---------|
| 70 | 0 | | | | | | Running 1 (Fwd) | | Faulted |
| | 1 | | | | | | | | |
| | 2 | Speed Actual (Low Byte) – RPM unit (note 1) | | | | | | | |
| | 3 | Speed Actual (High Byte) – RPM unit | | | | | | | |
| 71 | 0 | At Reference | Ref From Net | Ctrl From Net | Ready | Running 2 (Rev) | Running 1 (Fwd) | Warning | Faulted |
| | 1 | Drive State | | | | | | | |
| | 2 | Speed Actual (Low Byte) – RPM unit | | | | | | | |
| | 3 | Speed Actual (High Byte) – RPM unit | | | | | | | |
| 110 | 0 | | | | | | Running 1 (Fwd) | | Faulted |

| Instance | Byte | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|----------|------|--------------|--------------|---------------|-------|-----------------|-----------------|---------|--|
| | 1 | | | | | | | | |
| | 2 | | | | | | | | Speed Actual (Low Byte) – Hz unit (note 1) |
| | 3 | | | | | | | | Speed Actual (High Byte) – Hz unit |
| 111 | 0 | At Reference | Ref From Net | Ctrl From Net | Ready | Running 2 (Rev) | Running 1 (Fwd) | Warning | Faulted |
| | 1 | | | | | | | | Drive State |
| | 2 | | | | | | | | Speed Actual (Low Byte) – Hz unit |
| | 3 | | | | | | | | Speed Actual (High Byte) – Hz unit |
| | 0 | | | | | | | | Status Parameter - 1 data (Low Byte) |
| 141 | 1 | | | | | | | | Status Parameter - 1 data (High Byte) |
| | 0 | | | | | | | | Status Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Status Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Status Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Status Parameter - 2 data (High Byte) |
| 142 | 0 | | | | | | | | Status Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Status Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Status Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Status Parameter - 2 data (High Byte) |
| | 0 | | | | | | | | Status Parameter - 3 data (Low Byte) |
| 143 | 1 | | | | | | | | Status Parameter - 3 data (High Byte) |
| | 2 | | | | | | | | Status Parameter - 4 data (Low Byte) |
| | 3 | | | | | | | | Status Parameter - 4 data (High Byte) |
| | 4 | | | | | | | | Status Parameter - 5 data (Low Byte) |
| | 5 | | | | | | | | Status Parameter - 5 data (High Byte) |
| 144 | 0 | | | | | | | | Status Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Status Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Status Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Status Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Status Parameter - 3 data (Low Byte) |
| 145 | 5 | | | | | | | | Status Parameter - 3 data (High Byte) |
| | 6 | | | | | | | | Status Parameter - 4 data (Low Byte) |
| | 7 | | | | | | | | Status Parameter - 4 data (High Byte) |
| | 0 | | | | | | | | Status Parameter - 5 data (Low Byte) |
| | 1 | | | | | | | | Status Parameter - 5 data (High Byte) |
| 146 | 0 | | | | | | | | Status Parameter - 1 data (Low Byte) |

| Instance | Byte | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|----------|------|-------|-------|-------|-------|-------|-------|-------|---------------------------------------|
| 147 | 1 | | | | | | | | Status Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Status Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Status Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Status Parameter - 3 data (Low Byte) |
| | 5 | | | | | | | | Status Parameter - 3 data (High Byte) |
| | 6 | | | | | | | | Status Parameter - 4 data (Low Byte) |
| | 7 | | | | | | | | Status Parameter - 4 data (High Byte) |
| | 8 | | | | | | | | Status Parameter - 5 data (Low Byte) |
| | 9 | | | | | | | | Status Parameter - 5 data (High Byte) |
| | 10 | | | | | | | | Status Parameter - 6 data (Low Byte) |
| | 11 | | | | | | | | Status Parameter - 6 data (High Byte) |
| | 0 | | | | | | | | Status Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Status Parameter - 1 data (High Byte) |
| 148 | 2 | | | | | | | | Status Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Status Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Status Parameter - 3 data (Low Byte) |
| | 5 | | | | | | | | Status Parameter - 3 data (High Byte) |
| | 6 | | | | | | | | Status Parameter - 4 data (Low Byte) |
| | 7 | | | | | | | | Status Parameter - 4 data (High Byte) |
| | 8 | | | | | | | | Status Parameter - 5 data (Low Byte) |
| | 9 | | | | | | | | Status Parameter - 5 data (High Byte) |
| | 10 | | | | | | | | Status Parameter - 6 data (Low Byte) |
| | 11 | | | | | | | | Status Parameter - 6 data (High Byte) |
| | 12 | | | | | | | | Status Parameter - 7 data (Low Byte) |
| | 13 | | | | | | | | Status Parameter - 7 data (High Byte) |
| | 0 | | | | | | | | Status Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Status Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Status Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Status Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Status Parameter - 3 data (Low Byte) |
| | 5 | | | | | | | | Status Parameter - 3 data (High Byte) |
| | 6 | | | | | | | | Status Parameter - 4 data (Low Byte) |
| | 7 | | | | | | | | Status Parameter - 4 data (High Byte) |
| | 8 | | | | | | | | Status Parameter - 5 data (Low Byte) |
| | 9 | | | | | | | | Status Parameter - 5 data (High Byte) |
| | 10 | | | | | | | | Status Parameter - 6 data (Low Byte) |
| | 11 | | | | | | | | Status Parameter - 6 data (High Byte) |
| | 12 | | | | | | | | Status Parameter - 7 data (Low Byte) |
| | 13 | | | | | | | | Status Parameter - 7 data (High Byte) |

| Instance | Byte | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|----------|------|-------|-------|-------|-------|-------|-------|-------|---------------------------------------|
| | 14 | | | | | | | | Status Parameter - 8 data (Low Byte) |
| | 15 | | | | | | | | Status Parameter - 8 data (High Byte) |

The following table explains the data (bytes 0 and 1) for instances 70, 71, 110, and 111.

| Name | Description | Related attribute | |
|---------------|------------------------------|-------------------|----------|
| | | Class | Attr. ID |
| Faulted | Inverter Error | 0x29 | 10 |
| Warning | Not supported | 0x29 | 11 |
| Running1 | Motor is running Forward | 0x29 | 7 |
| Running2 | Motor is running Reverse | 0x29 | 8 |
| Ready | Motor is ready for operation | 0x29 | 9 |
| Ctrl From Net | Run/Stop control | 0x29 | 15 |
| Ref From Net | Speed control | 0x2A | 29 |
| At Reference | Reached reference Speed | 0x2A | 3 |
| Drive State | Current motor status | 0x29 | 6 |
| Actual speed | Reference speed | 0x2A | 7 |

③ Output instances

Output instances refer to the status data periodically sent from the PLC or other client devices to the inverter.

| Instance | Byte | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|----------|------|-------|-----------------|-----------------|-------|-------|-------------|--|---------|
| 20 | 0 | | | | | | Fault reset | | Run Fwd |
| | 1 | | | | | | 0 | | |
| | 2 | | | | | | | Speed Reference (Low Byte) – RPM unit | |
| | 3 | | | | | | | Speed Reference (High Byte) – RPM unit | |
| 21 | 0 | | NetRef (note 2) | NetCtrl (note2) | | | Fault reset | Run Rev | Run Fwd |
| | 1 | | | | | | 0 | | |
| | 2 | | | | | | | Speed Reference (Low Byte) – RPM unit | |
| | 3 | | | | | | | Speed Reference (High Byte) – RPM unit | |
| 100 | 0 | | | | | | Fault reset | | Run Fwd |
| | 1 | | | | | | 0 | | |
| | 2 | | | | | | | Speed Reference (Low Byte) – Hz unit | |
| | 3 | | | | | | | Speed Reference (High Byte) – Hz unit | |
| 101 | 0 | | NetRef | NetCtrl | | | Fault reset | Run Rev | Run Fwd |

| Instance | Byte | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|----------|------|-------|-------|-------|-------|-------|-------|-------|--|
| 121 | 1 | | | | | | | | 0 |
| | 2 | | | | | | | | Speed Reference (Low Byte) – Hz unit |
| | 3 | | | | | | | | Speed Reference (High Byte) – Hz unit |
| 122 | 0 | | | | | | | | Control Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Control Parameter - 1 data (High Byte) |
| 123 | 0 | | | | | | | | Control Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Control Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Control Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Control Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Control Parameter - 3 data (Low Byte) |
| 124 | 5 | | | | | | | | Control Parameter - 3 data (High Byte) |
| | 0 | | | | | | | | Control Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Control Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Control Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Control Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Control Parameter - 3 data (Low Byte) |
| | 5 | | | | | | | | Control Parameter - 3 data (High Byte) |
| | 6 | | | | | | | | Control Parameter - 4 data (Low Byte) |
| 125 | 7 | | | | | | | | Control Parameter - 4 data (High Byte) |
| | 0 | | | | | | | | Control Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Control Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Control Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Control Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Control Parameter - 3 data (Low Byte) |
| | 5 | | | | | | | | Control Parameter - 3 data (High Byte) |
| | 6 | | | | | | | | Control Parameter - 4 data (Low Byte) |
| | 7 | | | | | | | | Control Parameter - 4 data (High Byte) |
| 126 | 8 | | | | | | | | Control Parameter - 5 data (Low Byte) |
| | 9 | | | | | | | | Control Parameter - 5 data (High Byte) |
| | 0 | | | | | | | | Control Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Control Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Control Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Control Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Control Parameter - 3 data (Low Byte) |
| | 5 | | | | | | | | Control Parameter - 3 data (High Byte) |

| Instance | Byte | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|----------|------|-------|-------|-------|-------|-------|-------|-------|--|
| 127 | 6 | | | | | | | | Control Parameter - 4 data (Low Byte) |
| | 7 | | | | | | | | Control Parameter - 4 data (High Byte) |
| | 8 | | | | | | | | Control Parameter - 5 data (Low Byte) |
| | 9 | | | | | | | | Control Parameter - 5 data (High Byte) |
| | 10 | | | | | | | | Control Parameter - 6 data (Low Byte) |
| | 11 | | | | | | | | Control Parameter - 6 data (High Byte) |
| | 0 | | | | | | | | Control Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Control Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Control Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Control Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Control Parameter - 3 data (Low Byte) |
| | 5 | | | | | | | | Control Parameter - 3 data (High Byte) |
| | 6 | | | | | | | | Control Parameter - 4 data (Low Byte) |
| | 7 | | | | | | | | Control Parameter - 4 data (High Byte) |
| | 8 | | | | | | | | Control Parameter - 5 data (Low Byte) |
| | 9 | | | | | | | | Control Parameter - 5 data (High Byte) |
| 128 | 10 | | | | | | | | Control Parameter - 6 data (Low Byte) |
| | 11 | | | | | | | | Control Parameter - 6 data (High Byte) |
| | 12 | | | | | | | | Control Parameter - 7 data (Low Byte) |
| | 13 | | | | | | | | Control Parameter - 7 data (High Byte) |
| | 0 | | | | | | | | Control Parameter - 1 data (Low Byte) |
| | 1 | | | | | | | | Control Parameter - 1 data (High Byte) |
| | 2 | | | | | | | | Control Parameter - 2 data (Low Byte) |
| | 3 | | | | | | | | Control Parameter - 2 data (High Byte) |
| | 4 | | | | | | | | Control Parameter - 3 data (Low Byte) |
| | 5 | | | | | | | | Control Parameter - 3 data (High Byte) |
| | 6 | | | | | | | | Control Parameter - 4 data (Low Byte) |
| | 7 | | | | | | | | Control Parameter - 4 data (High Byte) |
| | 8 | | | | | | | | Control Parameter - 5 data (Low Byte) |
| | 9 | | | | | | | | Control Parameter - 5 data (High Byte) |
| | 10 | | | | | | | | Control Parameter - 6 data (Low Byte) |
| | 11 | | | | | | | | Control Parameter - 6 data (High Byte) |
| | 12 | | | | | | | | Control Parameter - 7 data (Low Byte) |
| | 13 | | | | | | | | Control Parameter - 7 data (High Byte) |
| | 14 | | | | | | | | Control Parameter - 8 data (Low Byte) |
| | 15 | | | | | | | | Control Parameter - 8 data (High Byte) |

The following table explains the data (bits for byte 0) for instances 20, 21, 100, and 101.

| Name | Description | Related attribute | |
|---------------------|---------------------|--------------------------|-----------------|
| | | Class | Attr. ID |
| Run Fwd (Note1) | Forward Run Command | 0x29 | 3 |
| Run Rev (Note1) | Reverse Run Command | 0x29 | 4 |
| Fault reset (Note1) | Fault Reset Command | 0x29 | 12 |
| NetRef (Note2) | Not used | 0x2A | 4 |
| NetCtrl (Note2) | Not used | 0x29 | 5 |
| Speed Reference | Reference speed | 0x2A | 8 |

(Note1) Refer to the Drive Run and Fault sections in the "Control Supervisor Object (Class 0x29)".

(Note2) Speed Reference and Run/Stop control can be set only on the LCD control panel.
Network control instances 21 and 101 (NetRef, NetCtrl) are not available.

10.2.3 Explicit Messages

Explicit messages refer to non-periodic data communications used for reading or writing attribute values of an inverter on an EtherNet/IP.

Using the UCMM communication (unconnected messages), data exchange is made without connecting the originator and the target, and periodic data exchange is available as well using the Class 3 connection.

10.2.4 Supported Objects

① Identity Object (Class 0x01, Instance 1)

Attribute

| Attribute ID | Access | Attribute Name | Data Length | Attribute Value |
|--------------|--------|---|-------------|-------------------|
| 1 | Get | Vendor ID | Word | 259 |
| 2 | Get | Device Type (inverter) | Word | 2 |
| 3 | Get | Product Code | Word | 100 (Note1) |
| 4 | Get | Revision High Byte - Major Revision Low Byte - Minor Revision | Word | (Note2) 0x0101 |
| 5 | Get | Status | Word | (Note3) |
| 6 | Get | Serial Number | Double Word | (Note4) |
| 7 | Get | Product Name | 4 Byte | CENT |

(Note1) Product Code 100 refers to the Benshaw inverter.

(Note2) The revision number is identical to the version of the EtherNet/IP. The high byte stands for a major revision number, and the low byte stands for a minor revision number. For example, "0x0101" stands for "version 1.01."

It is separate from the OS version of the communication option board (displayed on the Keypad COM-06 FBus S/W Ver).

(Note3) Definition of status bits

| Bit | Description |
|-----|--|
| 0 | 0: Device is not connected to the master 1: Device is connected to the master |
| 1 | Reserved |
| 2 | Configured (fixed as '0' because EtherNet/IP is not supported) |
| 3 | Reserved |
| 4 | 0: Unknown |
| 5 | 2: Faulty IO connection |
| 6 | 3: IO connection has not been made |
| 7 | 5: Major fault 6: IO connection has been made |
| 8 | Minor recoverable fault (Inverter is in warning status) |
| 9 | Minor unrecoverable fault (N/A) |
| 10 | Major recoverable fault (inverter H/W trip occurred) |
| 11 | Major recoverable fault (inverter non-H/W trip occurred) |

(Note4) Serial number uses the last 4 digits of the MAC ID.

Ex: The serial number is 0x29000022 when the MAC ID is "00:0B:29:00:00:22".

Service

| Service code | Definition | Support for class | Support for instance |
|--------------|----------------------|-------------------|----------------------|
| 0x0E | Get Attribute Single | No | Yes |
| 0x05 | Reset | No | Yes |
| 0x01 | Get Attribute All | No | Yes |

② Motor data object (Class 0x28, Instance 1)**Attribute**

| Attribute ID | Access | Attribute Name | Range | Definition |
|--------------|---------|------------------|--------------|---|
| 3 | Get | Motor Type | 0 – 10 | 0: Non-standard motor 1: PM DC Motor 2: FC DC Motor 3: PM Synchronous Motor 4: FC Synchronous Motor 5: Switched Reluctance Motor 6: Wound Rotor Induction Motor 7: Squirrel Cage Induction Motor 8: Stepper Motor 9: Sinusoidal PM BL Motor 10: Trapezoidal PM BL Motor |
| 6 | Get/Set | Motor Rated Curr | 0.0 – 1000.0 | [Get] Reads the value at MOT-05 Rated Curr. [Set] Set value is reflected to MOT-05 Rated Curr. Scale 0.1 |
| 7 | Get/Set | Motor Rated Volt | 0 – 690 | [Get] Reads the value of the MOT-07 Motor Voltage. [Set] Set value is reflected in the MOT-07 Motor Voltage. Scale 1 |

Service

| Service code | Definition | Support for class | Support for instance |
|--------------|----------------------|-------------------|----------------------|
| 0x0E | Get Attribute Single | No | Yes |
| 0x10 | Set Attribute Single | No | Yes |

③ Control Supervisor Objects (Class 0x29, Instance 1)**Attribute**

| Attribute ID | Access | Attribute Name | Range | Definition |
|--------------|---------|-------------------|-------|---|
| 3 | Get/Set | Forward Run Cmd. | 0 | Stopped |
| | | | 1 | Forward run (Note1) |
| 4 | Get/Set | Reverse Run Cmd. | 0 | Stopped |
| | | | 1 | Reverse run (Note1) |
| 5 | N/A | Net Control | - | Configurable only with the inverter parameter. |
| 6 | Get | Drive State | 0 | Vendor Specific |
| | | | 1 | Startup |
| | | | 2 | Not Ready (resetting in progress) |
| | | | 3 | Ready (stopping in progress) |
| | | | 4 | Enabled (running, not applicable to deceleration stop) |
| | | | 5 | Stopping (decelerating) |
| | | | 6 | Fault Stop |
| | | | 7 | Faulted (trip occurred) |
| 7 | Get | Running Forward | 0 | Drive stopped. |
| | | | 1 | Running Forward |
| 8 | Get | Running Reverse | 0 | Drive stopped. |
| | | | 1 | Running Reverse |
| 9 | Get | Drive Ready | 0 | Resetting in progress or trip occurred |
| | | | 1 | Inverter is ready for operation |
| 10 | Get | Drive Fault | 0 | Trip has not occurred |
| | | | 1 | Trip has occurred |
| 12 | Get/Set | Drive Fault Reset | 0 | Trip reset to release the trip. Resetting will begin only when the |

| Attribute ID | Access | Attribute Name | Range | Definition |
|--------------|--------|-------------------|-------|--|
| | | | 1 | value changes from FALSE to TRUE. (Note2) |
| 13 | Get | Drive Fault Codes | | Refer to the following Drive Fault Code table (Note2) |
| 15 | Get | Control From Net. | 0 | Commands are made using sources other than the DeviceNet communication. → Control is from local |
| | | | 1 | Commands are made using the DeviceNet communication as the source. → Control is from Network |

(Note1) Drive Run Inverter operation using Command Forward Run Cmd. and Reverse Run Cmd.

| Run1 | Run2 | Trigger Event | Run Type |
|-------|-------|---------------|----------|
| 0 | 0 | Stop | NA |
| 0 → 1 | 0 | Run | Run1 |
| 0 | 0 → 1 | Run | Run2 |
| 0 → 1 | 0 → 1 | No Action | NA |
| 1 | 1 | No Action | NA |
| 1 → 0 | 1 | Run | Run2 |
| 1 | 1 → 0 | Run | Run1 |

In the table above, Run1 indicates Forward Run Cmd. and Run 2 indicates Reverse Run Cmd. Commands are made by the EtherNet communication board when the value changes from 0 (FALSE) to 1 (TRUE). The Forward Run Cmd. value does not indicate the present operation status of the inverter; it indicates the operation command value on the EtherNet communication board.

(Note2) Drive Fault

The Drive Fault becomes TRUE when the inverter is faulted.

The Drive Fault Codes for the trips are as follows.

Drive Fault Codes

| Fault Code Number | Description | | |
|-------------------|---------------|----------------|-------------|
| 0x0000 | None | | |
| 0x1000 | Ethermal | Out Phase Open | InverterOLT |
| | InPhaseOpen | ThermalTrip | UnderLoad |
| | ParaWriteTrip | IOBoardTrip | PrePIDFail |
| | OptionTrip1 | OptionTrip2 | OptionTrip3 |
| | LostCommand | UNDEFINED | LostKeypad |

| Fault Code Number | Description | |
|-------------------|---------------|--------|
| 0x2200 | OverLoad | |
| 0x2310 | OverCurrent1 | |
| 0x2330 | GFT | |
| 0x2340 | OverCurrent2 | |
| 0x3210 | OverVoltage | |
| 0x3220 | LowVoltage | |
| 0x2330 | GroundTrip | |
| 0x4000 | NTCOpen | |
| 0x4200 | OverHeat | |
| 0x5000 | FuseOpen | HWDiag |
| 0x7000 | FanTrip | |
| 0x7120 | No Motor Trip | |
| 0x7300 | EncoderTrip | |
| 0x8401 | SpeedDevTrip | |
| 0x8402 | OverSpeed | |
| 0x9000 | ExternalTrip | BX |

Drive Fault Reset

The Drive Fault Reset gives TRIP RESET reference to the inverter when the setting value changes from 0 to 1 (FALSE to TRUE). Overwriting 1 (TRUE) over 1 (TRUE) does not generate RESET reference for a trip. To allow the EtherNet communication board to send a RESET command to the inverter when the value is 1 (TRUE), write 0 (FAULT) first, then write 1 (TRUE) again.

Service

| Service code | Definition | Support for class | Support for instance |
|--------------|----------------------|-------------------|----------------------|
| 0x0E | Get Attribute Single | No | Yes |
| 0x10 | Set Attribute Single | No | Yes |

④ Inverter Objects (Class 0x2A, Instance 1)

Attribute

| Attribute ID | Access | Attribute Name | Range | Definition |
|--------------|--------|----------------|-------|---|
| 3 | Get | At Reference | 0 | The output frequency has not reached the reference frequency. |
| | | | 1 | The output frequency has reached |

| Attribute ID | Access | Attribute Name | Range | Definition |
|--------------|---------|---------------------------|----------------|---|
| | | | | the reference frequency. |
| 4 | N/A | Net Reference | - | |
| 6 | Get | Drive Mode (Note1) | 0 | Vendor Specific Mode |
| | | | 1 | Open Loop Speed (Frequency) |
| | | | 2 | Closed Loop Speed Control |
| | | | 4 | Process Control (e.g. PI) |
| 7 | Get | SpeedActual | 0 – 24000 | Displays the present output frequency in [rpm]. |
| 8 | Get/Set | SpeedRef | 0 – 24000 | Displays the reference frequency in [rpm]. Reflected when DRV-07 (Freq Ref Src) is set to FieldBus. |
| 9 | Get | Actual Current | 0 – 111.0 A | Monitors the present current in 0.1 A increment/decrement. |
| 29 | Get | Ref.From Network | 0 | Command source is not the DeviceNet communication. |
| | | | 1 | Command source is the DeviceNet communication. |
| 100 | Get | Actual Hz | 0 – 400.00 Hz | Monitors the present operation frequency (Hz). |
| 101 | Get/Set | Reference Hz | 0 – 400.00 Hz | Speed reference may be given via a network communication if DRV-07 (Freq Ref Src) is set to 8 (FieldBus). |
| 102 | Get/Set | Acceleration Time (Note2) | 0 – 6000.0 sec | Sets/monitors the acceleration time of the inverter. |
| 103 | Get/Set | Deceleration Time (Note3) | 0 – 6000.0 sec | Sets/monitors the deceleration time of the inverter. |

(Note1) Related APP-01 (App Mode) settings. When APP-01 (App Mode) is set to Proc PID, MMC, then the Drive Mode becomes "Process Control (e.g. PI)."

(Note2) Value at DRV-03 (Acc Time)

(Note3) Value at DRV-04 (Dec Time)

Service

| Service code | Definition | Support for class | Support for instance |
|--------------|----------------------|-------------------|----------------------|
| 0x0E | Get Attribute Single | No | Yes |
| 0x10 | Set Attribute Single | No | Yes |

⑤ Class 0x64 (Inverter Object) – Manufacture Profile

This object is used to access the Keypad Parameters of the inverter.

Attribute

| Instance | Access | Attribute Number | Attribute Name | Attribute Value |
|----------------|---------|---|--|--|
| 1 (DRV Group) | Get/Set | Identical to the H2 Manual Code number. | H2 Keypad Title (Refer to the H2 inverter instruction manual) | Parameter setting range for the H2 inverter (Refer to the H2 inverter instruction manual) |
| 2 (MOT Group) | | | | |
| 3 (BAS Group) | | | | |
| 4 (ADV Group) | | | | |
| 5 (CON Group) | | | | |
| 6 (IN Group) | | | | |
| 7 (OUT Group) | | | | |
| 8 (COM Group) | | | | |
| 9 (PID Group) | | | | |
| 10 (AP1 Group) | | | | |
| 11 (AP2 Group) | | | | |
| 12 (AP3 Group) | | | | |
| 13 (PRT Group) | | | | |

Service

| Service code | Definition | Support for class | Support for instance |
|--------------|----------------------|-------------------|----------------------|
| 0x0E | Get Attribute Single | No | Yes |
| 0x10 | Set Attribute Single | No | Yes |

10.3 Modbus TCP Frame

10.3.1 Modbus TCP Frame Structure

| | |
|-----------------------|--------------------------|
| MBAP Header (7 bytes) | PDU (5 bytes or greater) |
|-----------------------|--------------------------|

In general, EtherNet communication uses EtherNet II frames.

MODBUS Application Protocol header (MBAP header)

The following table explains the components of a MBAP header.

| Section | Length | Description |
|------------------------|--------|--|
| Transaction identifier | 2 byte | Unique transmission number, which increases by 1 each time the client sends data frame to the server. |
| Protocol identifier | 2 byte | Fixed at 0. |
| Length | 2 byte | Data frame length of the Modbus communication, which represents the length (in byte unit) from the MBAP header to the unit identifier. |
| Unit identifier | 1 byte | When communications using Modbus TCP and Modbus RTU are connected via a gateway, the unit identifier indicates the slave number. The address is fixed to 0xFF when Modbus TCP communication is used alone. |

Protocol Data Unit (PDU)

PDU is the actual data in the Modbus TCP communication, which is composed of a function code and data.

Refer to "10.3.2 Function codes" below for detailed information.

10.3.2 Function Codes

The Modbus TCP communication involves clients and a server. During communication, clients send commands to the server, and the server responds to the commands. In general, devices such as a PLC, HMI, and PC are used as the client, and the inverter works as a server.

① Read Holding registers

Read Input registers are functions used to read the server (inverter) data.

The following table explains the components of a request data frame from a client to a server.

| Request frame | Length | Value |
|-------------------------|--------|------------------|
| Function code | 1 byte | 0x03 |
| Comm. address | 2 byte | 0x0000–0xFFFF |
| Number of data requests | 2 byte | 1–16 (Inverters) |

The following table explains the components of a response data frame from a server to a master.

| Response frame | Length | Value |
|-------------------------|-----------------------------------|---|
| Function code | 1 byte | 0x03 |
| Comm. address | 1 byte | 2 x the number of data requests |
| Number of data requests | Number of data requests x 2 bytes | Data value of the given number from the comm. address |

② Read Input registers

Read Input registers are functions used to read the server (inverter) data.

The following table explains the components of a request data frame from a client to a server.

| Request frame | Length | Value |
|-------------------------|--------|------------------|
| Function code | 1 byte | 0x04 |
| Comm. address | 2 byte | 0x0000–0xFFFF |
| Number of data requests | 2 byte | 1–16 (Inverters) |

The following table explains the components of a response data frame from a server to a master.

| Response frame | Length | Value |
|-------------------------|--------------------------------------|---|
| Function code | 1 byte | 0x03 |
| Comm. address | 1 byte | 2 x the number of data requests |
| Number of data requests | Number of data requests x 2 bytes | Data value of the given number from the comm. address |

③ Write Single register

Write Single registers are functions used to write a single server (inverter) data.

The following table explains the components of a request data frame from a client to a server.

| Request frame | Length | Value |
|---------------|--------|---------------|
| Function code | 1 byte | 0x06 |
| Comm. address | 2 byte | 0x0000–0xFFFF |
| Data value | 2 byte | 0x0000–0xFFFF |

The following table explains the components of a response data frame from a server to a master.

| Response frame | Length | Value |
|----------------|--------|---------------|
| Function code | 1 byte | 0x06 |
| Comm. address | 2 byte | 0x0000–0xFFFF |
| Data value | 2 byte | 0x0000–0xFFFF |

④ Write Multiple register

Write Multiple registers are functions used to write 1 to 16 consecutive data items on the server (inverter).

The following table explains the components of a request data frame from a client to a server.

| Request frame | Length | Value |
|-------------------------|------------------------|------------------------|
| Function code | 1bytes | 0x10 |
| Comm. address | 2bytes | 0x0000–0xFFFF |
| Number of data to write | 2byte | 1–16 (Inverters) |
| Byte Count | 1byte | 2 x the number of data |
| Number of data to | The number of data x 2 | Data to write |

| Request frame | Length | Value |
|---------------|--------|-------|
| write | bytes | |

The following table explains the components of a response data frame from a server to a master.

| Response frame | Length | Value |
|-------------------------|--------|------------------|
| Function code | 1 byte | 0x10 |
| Comm. address | 2 byte | 0x0000–0xFFFF |
| Number of data to write | 2 byte | 1–16 (Inverters) |

⑤ Read/Write Multiple register

Read/Write Multiple registers are functions used to write 1 to 16 consecutive data items on the server (inverter). At the same time this function is used to read data items on the sever (inverter).

The following table explains the components of a request data frame from a client to a server.

| Request frame | Length | Value |
|-------------------------|------------------------|------------------------|
| Function code | 1bytes | 0x17 |
| Comm. address | 2bytes | 0x0000 ~ 0xFFFF |
| Number of data to write | 2byte | 1–16 (inverters) |
| Byte Count | 1byte | 2 x the number of data |
| Value of data to write | The number of data x 2 | Data to write |

The following table explains the components of a response data frame from a server to a master.

| Request frame | Length | Value |
|-------------------------|------------------------|---|
| Function Code | 1 Bytes | 0x17 |
| Comm. address | 1 Bytes | 2 x the number of data |
| Number of data to write | The number of data x 2 | Data value of the given number from the comm. address |

10.3.3 Exception (Except) Frame

An exception frame is a response frame from a server when an error occurs while responding to the client.

The following table explains the components of an exception frame.

| Error frame | Length | Value |
|----------------|--------|--|
| Error code | 1bytes | 0x80 + function code requested by the client |
| Exception code | 1bytes | 0x0000–0xFFFF |

Exception code

| Type | Code | Description |
|-----------------------|------|--|
| ILLEGAL FUNCTION | 0x01 | Unsupported function has been requested |
| ILLEGAL DATA ADDRESS | 0x02 | An unused address has been requested or modification has been requested for the data at an unused address. |
| ILLEGAL DATA VALUE | 0x03 | A data modification request has been made out of the range of the available value. |
| SLAVE DEVICE FAILURE | 0x04 | Server error occurred (CAN communication error with the drive, communication board initialization error, or data communication error with the drive) |
| SLAVE DEVICE BUSY | 0x06 | Server is unable to respond because it is executing another process (in the middle of a drive parameter initialization or the initial setting of the communication board) |
| WRITE PERMITION ERROR | 0x20 | Unique code for Benshaw Inverters. An attempt was made to change a write-protected parameter |

10.4 LED Indications and Troubleshooting

| LED name | Color | Description | Status | Status |
|----------|--------|-------------------------|--------|---|
| LINK1 | Green | Network normal | ON | Network connection at LINK 1 is operating normal |
| | Orange | Check network settings | ON | Check EtherNet settings*1 When the communication cycle stops for longer than one second. |
| | - | LINK 1 Not connected | OFF | Trying EtherNet communication, network cable not connected to LINK 1 |
| LINK2 | Green | Network normal | ON | Network connection at LINK 2 is operating normal |
| | Orange | Network fault | ON | Check EtherNet settings*1 |
| | - | LINK 1 Not connected | OFF | Trying EtherNet communication, network cable not connected to LINK 2 |

*1: For EtherNet network settings, check keypad parameters COM-10, COM-11, COM-14, COM-15, COM-23, and COM-24, and the settings for the client devices, such as the PLC.

| LED name | Color | Description | Status | Status |
|----------|-------|------------------|---|--|
| ERROR | Red | Normal operation | OFF | Communication between the communication board and the inverter is normal. |
| | | Network fault | Flashing Synchronous with CPU LED (1 second interval) | Communication between the communication board and the inverter is abnormal. |
| | | | Flashing (2 second interval) | The communication board parameters are set differently from the communication parameter settings on the keypad*2 |
| | | | ON | EEPROM failure No network connection to LINK 1 and LINK 2 IP collision occurred |
| CPU | Green | Normal operation | Flashing (1 second interval) | The communication board has been properly installed on the inverter. |

*2: To synchronize the EtherNet communication board settings with the keypad parameter settings, check the COM Group parameter settings and set COM-94 (Comm. Update) to "1 (yes)."

11 Revision History

| Rev. | Date | Edition | Software | Date | Changes |
|------|-----------|----------|----------|------------|-------------------|
| 00 | 6/21/2021 | Standard | 201.00 | 11/26/2020 | Initial Release |
| 01 | 2/4/2021 | Standard | 201.00 | 11/26/2020 | See Release Notes |
| | | | | | |
| | | | | | |
| | | | | | |



BENSHAW
Applied Motor Controls

BENSHAW
615 Alpha Drive
Pittsburgh, PA 15238
Phone: (412) 968-0100
Fax: (412) 968-5415

BENSHAW Canada
550 Bright Street
Listowel, Ontario N4W 3W3
Phone: (519) 291-5112
Fax: (519) 291-2595