

# Benshaw Connect Help

## Contents

Getting Started.....	4
Installing Benshaw Connect.....	4
Launching the Program .....	4
View Type .....	4
Connection Settings.....	5
Device Type .....	5
Profile .....	5
Node Number .....	5
IP Address .....	5
COM Port .....	6
Other Serial Settings .....	6
Restore Connection Settings .....	6
Connection and Load.....	7
Device Version.....	7
Connection Options.....	7
Basic Use .....	8

Identity Information .....	8
Parameters .....	8
Meters .....	9
Faults and Events .....	9
Reports.....	10
Save Values .....	10
Run Report .....	10
View Report files .....	11
Import Parameters .....	11
Graphical Controls .....	12
Main Status and Control.....	12
Medium Voltage Drive HMI View .....	12
Real Time Plot.....	13
Open a Real Time Plot Window .....	13
Add Registers .....	13
Display Settings.....	14
Individual Settings .....	14
Save and Load .....	14
Trouble Shooting.....	15

Error Connecting .....	15
Failed Connection (Red Connection Status).....	15
Failed to Read Some Registers (blank values) .....	16
Failed to Write a Parameter Value .....	16

# Getting Started

## Installing Benshaw Connect

1. If you have a previous version of Benshaw Connect installed, uninstall it from the programs menu of your computer.
  - Existing work files and reports will not be deleted by the uninstall process.
  - The Benshaw Connect Event Viewer does not need to be uninstalled.
2. Install Benshaw connect by opening the provided “Setup” file.

## Launching the Program

1. Choose device and connection type from this screen.
2. Settings are loaded from most recent connection attempt, simply click “connect” to continue.
3. Click “settings” if changes are required.



## View Type

1. For some devices, multiple view types are available.
  - Use “list” view to hide graphical controls and make the parameter and meter list full screen.
  - Use “graphics” view to hide the parameter list and use graphical controls only.

# Connection Settings

## Device Type

- MV Drive, MX2, MX3, and SG Drive are supported.

## Profile

- Different Parameter and meter lists for some devices.
- Use “test” view to load and display all exposed parameters and meters.

## Node Number

- For TCP connections, the node number can always be set to 1.
- For serial connections, the node

number must match the node number for the specific device and network.

## IP Address

- For TCP connections only
- The default IP address for Medium Voltage Drives is 172.29.87.10 for recent releases and 192.168.1.2 for older versions.
- A full history of previously used IP addresses is available by using the dropdown arrow.

The screenshot shows the 'Connection Settings' dialog box. At the top, there are two buttons: 'Defaults' and 'Saved Settings'. Below these, the 'Device Type' is set to 'MV Drive' in a dropdown menu. The 'Profile' is set to 'customer' in another dropdown. The 'Connection Type' has two radio buttons: 'TCP(Ethernet)' (which is selected) and 'Serial'. Below this, the 'Node Number' is set to '1' in a text field. The 'TCP' section is expanded, showing 'IP Address' as '172.29.87.10' in a dropdown and 'Port' as '502' in a text field. The 'Serial' section is also visible but not selected, showing 'COM Port' and 'Baud Rate' dropdowns. Under 'Parity', 'None', 'Odd', and 'Even' are radio buttons, with 'Even' selected. Under 'Data Bits', '7' and '8' are radio buttons, with '8' selected. Under 'Stop Bits', '1', '1.5', and '2' are radio buttons, with '1' selected. A 'Protocol' section shows 'Modbus RTU' and 'Modbus ASCII' as radio buttons, with 'Modbus RTU' selected. At the bottom right, there are 'OK' and 'CANCEL' buttons.

## COM Port

- For Serial connections only.
- Corresponds to the port on your computer where the serial cable is connected.
  - Open the windows device manager to view active ports.

## Other Serial Settings

- Default values will match the most current communication specifications for the selected device.
- Older MX3 devices may use no parity instead of even parity.
- SG drives have a variable baud rate. Check I/O 91 on the keypad for the current rate

## Restore Connection Settings



- Clicking the “defaults” button will reset all fields to a default state.
- Click “saved settings” to reload the most recently used values.
  - Different saved settings are saved for each device and for both connection types.

The screenshot shows a 'Connection Settings' dialog box. At the top, there are two buttons: 'Defaults' and 'Saved Settings'. Below these, the 'Device Type' is set to 'MX3' in a dropdown menu. The 'Profile' is set to 'test' in another dropdown. The 'Connection Type' has two radio buttons: 'TCP(Ethernet)' and 'Serial', with 'Serial' being selected. Below this, the 'Node Number' is set to '1' in a text field. There are two sections: 'TCP' and 'Serial'. The 'TCP' section is currently active, showing 'IP Address' as '192.168.1.200' and 'Port' as '502'. The 'Serial' section is collapsed. When expanded, it shows 'COM Port' as 'COM4', 'Baud Rate' as '19.2K', 'Parity' as 'Even' (selected over 'None' and 'Odd'), 'Data Bits' as '8' (selected over '7'), and 'Stop Bits' as '1' (selected over '1.5' and '2'). A 'Protocol' section is also visible, with 'Modbus RTU' selected over 'Modbus ASCII'. At the bottom right are 'OK' and 'CANCEL' buttons.

# Connection and Load


## Device Version

- On a good connection, the version number is read from the device and a matching source file is chosen.
- If the connection fails or an unknown version is present, the user will be prompted to select a file.
- New or updated files can be added to this folder later using *File > XML Profiles*.



## Connection Options


- Use “connect” and “disconnect” to control when values are read from the device.
- Choose a different scan rate to change how often values are updated and manage network traffic.



# Basic Use


## Identity Information

- To help distinguish between multiple open instances of Benshaw Connect, basic identifying information appears in the title bar.
  - Device type and version.
  - IP address or serial node number.



## Parameters

- Parameters are editable values that affect the behavior of the connected device.
- To edit a parameter value, double click on any parameter in the list view or press the enter key while the desired parameter is highlighted.
  - Type a value within the allowed range and click or press enter.



- Parameters that have been changed to values other than the default will be highlighted in yellow.

Group	Description	Value	Default	Register
QST 01	Motor FLA	10 Arms	10 Arms	40101
QST 02	Motor Service Factor	1.15	1.15	40102
QST 03	Running Overload Enable	1: On	1: On	40104
QST 04	Running Overload Class	10	10	40105
QST 05	Local Source	2: Serial	1: Terminal	40110
QST 06	Remote Source	1: Terminal	1: Terminal	40111



## Meters

- Meters display important diagnostic information about the connected device.
- Meters have no default values and cannot be written to.

## Faults and Events


- The Fault and Event tabs display information on recent events.
- These tabs are not present for all devices; a separate “Event Viewer” program is used for medium voltage drive event logs.

Parameters	Meters	Fault Log	Event Log	
Event #	Event	System State	Time Stamp	
1	Stop Complete	Faulted	7:34:41 AM 1/7/2016	
2	Stop Commanded	Faulted	7:34:41 AM 1/7/2016	
3	No Line	Stopped	7:34:40 AM 1/7/2016	
4	Start Commanded	Stopped	7:34:37 AM 1/7/2016	

# Reports

## Save Values

- Clicking *Reports > Save Values* will create an xml file of all data available in the list view.
- Select any file name to generate this xml. By default, a different folder is used for each device type.



## Run Report

- Select *Reports > Display Report* or *Reports > Display Report with Meters* to generate a graphical report of previously saved data.
- Select an xml file to generate a report html file with the same name.
- Highlighted parameter and event values will appear in the report with similar formatting to the list view.

A screenshot of a web browser displaying a report titled 'Benshaw Soft Starter Settings and Events'. The report includes metadata like 'File: MX3', 'Device: MX3 Starter', and 'Date Recorded: 1/6/2016 2:48:50 PM'. It contains two main tables: 'Quick Start' and 'Control Functions'.

Name	Description	Value	Default	Register
QST 01	Motor FLA	10 Arms	10 Arms	40101
QST 02	Motor Service Factor	1.15	1.15	40102
QST 03	Running Overload Enable	1: On	1: On	40104
QST 04	Running Overload Class	10	10	40105
QST 05	Local Source	2: Serial	1: Terminal	40110
QST 06	Remote Source	1: Terminal	1: Terminal	40111
QST 07	Initial Current 1	100 %FLA	100 %FLA	40113
QST 08	Maximum Current 1	600 %FLA	600 %FLA	40114
QST 09	Ramp Time 1	15 sec	15 sec	40115
QST 10	UTS Time	20 sec	20 sec	40119

Name	Description	Value	Default	Register
CFN 01	Start Mode	1: Current Ramp	1: Current Ramp	40112
CFN 02	Ramp Time 1	15 sec	15 sec	40115
CFN 03	Initial Current 1	100 %FLA	100 %FLA	40113
CFN 04	Maximum Current 1	600 %FLA	600 %FLA	40114
CFN 05	Ramp Time 2	15 sec	15 sec	40118
CFN 06	Initial Current 2	100 %FLA	100 %FLA	40116
CFN 07	Maximum Current 2	600 %FLA	600 %FLA	40117
CFN 08	Initial V/T/P	1 %	25 %	40120
CFN 09	Max T/P	105 %	105 %	40121
CFN 10	Accel Profile	0: Linear	0: Linear	40221
CFN 11	Kick Enable 1	0: Off	0: Off	40129
CFN 12	Kick Level 1	100 %FLA	100 %FLA	40130

A screenshot of a web browser displaying a report titled 'Faults' and 'Events'. The 'Faults' table lists various fault conditions with their system states, current/voltage readings, and run times. The 'Events' table lists system events with their event numbers, descriptions, system states, and timestamps.


#	Fault	System State	Currents: L1 L2 L3	Voltages: L1-L2 L2-L3 L3-L1	Kilowatts	Frequency	Run Time	OL Class: Run Ramp
1	No Line	Stopped	0 Amp 0 Amp 0 Amp	10 Volt 0 Volt 15 Volt	0 kW	166.67 Hz	116 : 0 : 0.0	10 10
2	No Line	Stopped	0 Amp 0 Amp 0 Amp	11 Volt 0 Volt 16 Volt	0 kW	166.67 Hz	116 : 0 : 0.0	0 0
3	No Line	Stopped	0 Amp 0 Amp 0 Amp	11 Volt 0 Volt 17 Volt	0 kW	166.67 Hz	116 : 0 : 0.0	0 0
4	No Line	Stopped	0 Amp 0 Amp 0 Amp	11 Volt 1 Volt 15 Volt	0 kW	166.67 Hz	116 : 0 : 0.0	0 0
5	No Line	Stopped	0 Amp 0 Amp 0 Amp	11 Volt 0 Volt 15 Volt	0 kW	166.67 Hz	116 : 0 : 0.0	0 0
6	No Line	Stopped	0 Amp 0 Amp 0 Amp	11 Volt 1 Volt 15 Volt	0 kW	166.67 Hz	116 : 0 : 0.0	0 0
7	No Line	Stopped	0 Amp 0 Amp 0 Amp	10 Volt 1 Volt 15 Volt	0 kW	166.67 Hz	116 : 0 : 0.0	0 0
8	No Line	Stopped	0 Amp 0 Amp 0 Amp	11 Volt 0 Volt 15 Volt	0 kW	166.67 Hz	116 : 0 : 0.0	0 0
9	No Line	Stopped	0 Amp 0 Amp 0 Amp	11 Volt 1 Volt 15 Volt	0 kW	166.67 Hz	116 : 0 : 0.0	0 0

Event Number	Event	System State	Time
1	Stop Complete	Faulted	1:52:46 PM 1/6/2016
2	Stop Commanded	Faulted	1:52:46 PM 1/6/2016
3	No Line	Stopped	1:52:46 PM 1/6/2016
4	Start Commanded	Stopped	1:52:43 PM 1/6/2016
5	System Powered Up	Initializing	9:53:36 AM 1/6/2016
6	System Powered Down	Stopped	3:45:02 PM 1/4/2016
7	Low Voltage Reset Detected	Tripped	3:45:02 PM 1/4/2016

## View Report files

- Click *File > Saved Reports* to view the reports file folder.
  - The report files can then be copied to another location for use outside of Benshaw Connect.
  - Folders will be present for any device that has been used to generate a report.




## Import Parameters

- Parameter values stored in the report can be used to write saved values back to the device.
  - Save an xml report of the desired values.
  - To revert to these values later, click *Reports > Import Parameters* and select the appropriate xml file from the file explorer.
  - Benshaw connect will write values to every parameter that varies from the saved xml.

# Graphical Controls

## Main Status and Control

- Running/Stopped and other status is displayed across the top of the interface.
- When the device is configured for network control, start and stop buttons will appear next to the status indicators.



## Medium Voltage Drive HMI View


- For MV Drives, the left half of the screen will duplicate data available on the HMI touch screen.
- Speed output, cell status, lockouts, and other information is displayed on different tabs.



# Real Time Plot

## Open a Real Time Plot Window

- Click *Advanced > Real Time Plot* to open a new plot window.
- Alternatively, right click any parameter or meter from the list and select “Plot Value” to open a window with that value already added.



## Add Registers

- To add a register to the window, type the address into the top text field and click “Add”
- Existing values from the list view will be added with their associated names.
- This window can also be used to poll addresses not listed in the xml profile. These values will display the address in place of a name.

## Display Settings


- By default, the vertical range of the graph is scaled to fit new values. This range can be adjusted manually using the “Min” and “Max” text fields.
- “Data Points” controls the number of values shown on the screen at a time, and “Update Interval” controls the rate at which new values are added.

## Individual Settings

- Chosen with the dropdown control, the “Active Meter” area displays the value and settings for one meter at a time.
- The “Multiplier” and “Y Offset” settings can be changed for each meter. When multiple meters are displayed in the same window, these settings allow the trend lines to be vertically aligned or separated.

## Save and Load


- Like reports, the full plot can be saved at any time.
- The data points can then be loaded for later analysis.
- The load feature can also be used to restore display settings only, where new values will be read from the same meters.



# Trouble Shooting

## Error Connecting

- If the program fails to connect on launch, the device cannot be polled for a correct version file, and the user will have to select one.
  - Click “Cancel” to return to the launch screen and try again, or “OK” to continue in offline mode and choose a file manually.
- Possible Causes:
  - The selected Com Port is unavailable. Verify that your serial device is connected to the Com Port specified in the **Connection Settings**.
  - The Connection Settings are incorrect for the connected device. Click “Settings” to review and change settings before reconnecting.
  - Incorrect IP Address. For TCP connections, the IP address of your PC must be compatible with the device address. Open the windows command prompt and try pinging the device to ensure the correct IP address was Chosen.



## Failed Connection (Red Connection Status)



- In the case of a failed connection, Benshaw Connect will continue attempting to read values and will reconnect automatically if the device becomes available.
- Upon reconnection, the Status bar will change to green and display “Connected.”

- Possible Causes:
  - The device is not powered.
  - The selected IP Address is not correct. Try pinging the device from the windows command prompt.
  - Your computer IP Address is not compatible with the device IP address. The first three sets of numbers must match the device. (172.29.87.X or 192.168.1.X depending on device and version)
  - The serial node number does not match. Check that the node number on the device keypad matches connection settings.

**Failed to Read Some Registers (blank values)**

- Cells can be left blank if the registers are not mapped on the connected device.
  - Verify that the device version matches the source file version.
- The connection may have been lost before all values could be loaded. If the indicator is red, fixing the connection issue should cause the rest of the values to load.

Group	Description	Value	Register
RTM 22	Output Frequency		40400
RTM 10	Motor Current		40401
RTM 21	Motor Voltage		40402
RTM 02	DC Bus Voltage		40403

**Failed to Write a Parameter Value**

- Make sure that the device is connected. (green “Connection Satus”)
- Allow time for the new value to load. Depending on the scan rate and number of registers, the program could take several seconds to refresh and read the new value.



- For SG drives, a limiting parameter might be affecting the range. For example, the drive will not allow frequency parameters to exceed the Maximum frequency at register 437406, even if the listed range is greater.
- Check version compatibility; if an incorrect xml profile was chosen, the actual enforced range may differ from the displayed value.