# Profibus

Communications option for EMX4e/EMX4i soft starters

**User Guide** 



## 710-21972-00A

©2020 Benshaw, Inc

Benshaw retains the right to change specifications and illustrations in text without prior notification. The contents of this document may not be copied without the explicit permission of Benshaw.

# **Product Compatibility**

This expansion card is suitable for use with EMX4e and EMX4i soft starters.

Product description	Soft starter name
Basic model	EMX4e
Advanced model	EMX4i

# Parameter Management

Parameter lists vary according to the model and version of soft starter.

Refer to the relevant soft starter literature for a complete parameter list.

For the latest manuals and software, please visit our website.

# Contents

Disclaimer	2
Warnings	2
Important User Information	. 2
Installation	3
Configuration	4
Data Structures	. 5
Profibus Diagnostic Telegram and Flag	11
Profibus Freeze Mode	11
Profibus Sync Mode	11
Profibus Clear Mode	11
Specifications	12
	Disclaimer

# 1 Disclaimer

The examples and diagrams in this manual are included solely for illustrative purposes. The information contained in this manual is subject to change at any time and without prior notice. In no event will responsibility or liability be accepted for direct, indirect or consequential damages resulting from the use or application of this equipment.

# 2 Warnings



### WARNING

For your safety, isolate the soft starter from mains voltage before attaching or removing accessories.



## WARNING

Inserting foreign objects or touching the inside of the starter while the expansion port cover is open may endanger personnel, and can damage the starter.

# 3 Important User Information

Observe all necessary safety precautions when controlling the soft starter remotely. Alert personnel that machinery may start without warning.

It is the installer's responsibility to follow all instructions in this manual and to follow correct electrical practice.

Use all internationally recognised standard practice for RS-485 communications when installing and using this equipment.

## 4 Installation

## 4.1 Installing the Expansion Card

- 1. Push a small flat-bladed screwdriver into the slot in the centre of the expansion port cover, and ease the cover away from the starter.
- 2. Line up the card with the expansion port. Gently push the card along the guide rails until it clicks into the starter.



## 4.2 Connecting to the Network

After the card is in place, control power can be restored and field wiring can be connected via the DB9 plug.

DB9 connector		
Pin No.	Assignment	
1	Shield	
2	24 VDC negative (optional)	
3	RxD/TxD-P	
4	Not used	
5	DGND	
6	VP (end of bus slave only)	
7	24 VDC positive (optional)	
8	RxD/TxD/-N	
9	DGND	

## 4.3 Feedback LEDs

	Off	On
Power (red)	Device is not powered up.	Device is powered up and ready to go online
Network (green)	No connection, offline or data exchange failure	Device is online and in data exchange state



#### NOTE

If communication is inactive, the soft starter may trip on Network Communications. If parameter 6M *Network Communications* is set to 'Soft Trip and Log' or 'Trip Starter', the soft starter will require a reset.



## NOTE

If communication fails between the device and the network, the Bus Status LED will go off. When communication is restored, the Bus Status LED will come back on.

# 5 Configuration

Import the latest .gsd file into your Master configuration tool. This file is available from your supplier.

If your Master uses on-screen icons, two graphic bitmap files are available from the website. SSPM\_N.bmp indicates normal mode. SSPM\_D.bmp indicates diagnostic mode.

## 5.1 Profibus Address

The network address for the card must be set via the soft starter (parameter 12G *Profibus Address*). For details on how to configure the soft starter, see the soft starter user manual.

_	
=	

#### NOTE

The Profibus Card will read the network address from the soft starter when control power is applied. If parameters are changed in the starter, control power must be cycled for the new values to take effect.

## 5.2 Enabling Network Control

The soft starter will only accept commands from the Profibus Card if parameter 1A *Command Source* is set to 'Network'.

r		
	=	
	_	

#### NOTE

If the reset input is active, the starter will not operate. If a reset switch is not required, fit a link across terminals 10, 11 on the soft starter.

If the Profibus network fails, the device will leave data exchange mode after the network watchdog timeout period has expired. This timeout period is set at the Master configuration tool.

A Communication Timeout parameter in the GSD file sets how soon after this event the soft starter will be forced into a trip state.

The user can adjust the Communication Timeout parameter in the GSD file to any setting between 0 and 100 seconds. The default setting is 10 seconds.

Г	<u> </u>
L	
L	
L	
L	
L	
L	

#### NOTE

If the Communication Timeout parameter is set to 0, the current state of the soft starter will remain unchanged on a network failure. This gives the user the option of operating the soft starter via local control, but is NOT failsafe.

# 6 Data Structures

The GSD file contains three operating modules, supporting data I/O structures as follows:

Data Structure	Basic Module	Extended Module	Parameter Upload/ Download Module
Soft Starter Control I/O Data Structure on page 6	$\checkmark$	$\checkmark$	~
Soft Starter Monitoring I/O Data Structure on page 7	×	$\checkmark$	$\checkmark$
Soft Starter Programming I/O Data Structure on page 9	×	×	✓

The Basic Module allows the user to start and stop the soft starter and read limited information on operating status.

The Extended Module defines additional bytes allowing the user to read soft starter operating data such as actual motor current and motor temperature.

The Parameter Upload/Download Module allows the user to read and write soft starter parameter values.



#### NOTE

The available features and parameter details may vary according to the model and software version of the starter. Refer to the soft starter user manual for details of parameters and supported features.

## 6.1 Soft Starter Control I/O Data Structure

Master > Slave control word is structured as follows:

Byte	Bits	Details
0	0 to 1	Reserved
	2 to 3	0 = Use soft starter remote input to select motor set
		1 = Use primary motor set when starting
		2 = Use secondary motor set when starting
		4 = Reserved
	4	0 = stop action will be a soft stop (as selected on the soft starter)
		1 = stop action will be a quick stop (ie coast to stop)
	5 to 7	Reserved
1	0	0 = Stop
		1 = Start
	1 to 2	Reserved
	3	1 = Reset
	4 to 7	Reserved



#### NOTE

Bit 4 of byte 0 must be set to 0 for the soft starter to perform a start.

#### Slave > Master status word is structured as follows:

Byte	Bits	Details	
0	0 to 5	Motor current (% FLC)	
	6	Command source	
		0 = Network	
		1 = Remote Keypad, Digital Input, Clock	
	7	1 = Ramping (starting or stopping)	
1	0	1 = Ready	
11 = Starting, running or stopping21 = Tripped31 = Warning4 to 7Reserved		1 = Starting, running or stopping	
		1 = Tripped	
		1 = Warning	
		Reserved	

<sup>1</sup> Motor current (% FLC) represents current as a percentage of the set motor full load current. A maximum value of 63 represents 200% full load current. To convert this value to a readable percentage, divide by 0.315. For models 0064B and smaller this value will be 10 times greater than the value displayed on the keypad.

## 6.2 Soft Starter Monitoring I/O Data Structure

Master > Slave output bytes are structured as follows.

#### Byte 2

Operating data request (Data request numbers 1 to 16)

Slave > Master input bytes, in response to an operating data request, are structured as follows:

#### Byte 2

Echo data request number

#### Byte 3

Bits 7 to 1 Reserved

#### Byte 4

Data value (high byte)

#### Byte 5

Data value (low byte)



#### NOTE

An invalid data request number will result in the invalid data request number bit being set = 1.

Bit 0 = 1: Invalid data request number

Data values are defined as follows:

Data Request Number	Description	Bits	Details
0	Reserved		
1	Product information	0 to 7	Reserved
		8 to 15	Product type code: 12 = basic model 13 = advanced model
2	Starter state	0 to 3	<ul> <li>1 = Ready</li> <li>2 = Starting</li> <li>3 = Running</li> <li>4 = Stopping (including braking)</li> <li>5 = Not ready (restart delay, restart temperature check, run simulation, reset input is open)</li> <li>6 = Tripped</li> <li>7 = Programming mode</li> <li>8 = Jog forward</li> <li>9 = Jog reverse</li> </ul>
		4	0 = Negative phase sequence 1 = Positive phase sequence (only valid if bit 6 = 1)
		5	1 = Current exceeds FLC
		6	0 = Uninitialised 1 = Initialised
		7	1 = Communication error between device and soft starter
		8 to 15	See Trip Codes on page 9

Data Request Number	Description	Bits	Details
3	Motor current	0 to 7	Average rms current across all three phases (low byte)
		8 to 15	Average rms current across all three phases (high byte)
4	Motor temperature	0 to 7	Motor thermal model (%)
		8 to 15	Reserved
5	% Power factor	0 to 7	100% = power factor of 1
		8 to 15	Reserved
6	Power (kW)	0 to 11	Power
		12 to 15	Power scale
			0 = Multiply power by 10 to get W
			1 = Multiply power by 100 to get W
			2 = Power (kW)
			3 = Multiply power by 10 to get kW
7	Power (kVA)	0 to 11	Power
		12 to 15	Power scale
			0 = Multiply power by 10 to get VA
			1 = Multiply power by 100 to get VA 2 = Power (k)(A)
			2 = FOWEI (KVA) 3 = Multiply power by 10 to get k)/A
8	Voltage	0 to 13	Average rms voltage across all three phases
0	Voltage	14 to 15	Reserved
9	Current	0 to 13	Phase 1 current (rms)
Ŭ	Guildin	14 to 15	Reserved
10	Current	0 to 13	Phase 2 current (rms)
	ourrone	14 to 15	Reserved
11	Current	0 to 13	Phase 3 current (rms)
		14 to 15	Reserved
12	Voltage	0 to 13	Phase 1 voltage
		14 to 15	Reserved
13	Voltage	0 to 13	Phase 2 voltage
		14 to 15	Reserved
14	Voltage	0 to 13	Phase 3 voltage
		14 to 15	Reserved
15	Version	0 to 7	Software minor revision number
		8 to 15	Software major version number
16	Digital input state		For all inputs, 0 = open, 1 = closed (shorted)
		0	Start/Stop
		1	Reserved
		2	Reset
		3	Input A
		4	Input B
		5 to 15	Reserved

## 6.3 Soft Starter Programming I/O Data Structure

The Soft Starter Programming I/O Data Structure allows the user to upload (read) and download (write) soft starter parameter values over the network.



**CAUTION** Do not change the default values of the Advanced parameters (parameter group 20). Changing these values may cause unpredictable behaviour in the soft starter.

## Outputs

Master > Slave output bytes are structured as follows.

Byte	Bits	Details
3	0 to 7	Parameter number to read/write
4	0	Reserved
	1	1 = Read parameter
	2	1 = Write parameter
	3 to 7	Reserved
5	0 to 7	High byte parameter value to write to soft starter/ zero data values for read
6	0 to 7	Low byte parameter value to write to soft starter/ zero data values for read

#### Inputs

Slave > Master input bytes are structured as follows.

Byte	Bits	Details
6	0 to 7	Echo parameter number
7	0	1 = Invalid parameter number
	1	1 = Invalid parameter value
	2 to 7	Reserved
8	0 to 7	High byte parameter value read from soft starter
9	0 to 7	Low byte parameter value read from soft starter

# 6.4 Trip Codes

Trip Code	Description		
0	No trip		
1	Excess start time		
2	Motor overload		
3	Motor thermistor		
4	Current imbalance		
5	Frequency		
6	Phase sequence		
7	Instantaneous overcurrent		
8	Power loss		
9	Undercurrent		
10	Heatsink overtemperature		
11	Motor connection		
12	Input A trip		

Trip Code	Description		
13	FLC too high		
14	Unsupported option (function not available in inside delta)		
15	Communications card fault		
16	Forced network trip		
17	Internal fault		
18	Overvoltage		
19	Undervoltage		
23	Parameter out of range		
24	Input B trip		
26	L1 phase loss		
27	L2 phase loss		
28	L3 phase loss		
29	L1-T1 shorted		
30	L2-T2 shorted		
31	L3-T3 shorted		
33	Time-overcurrent (Bypass overload)		
34	SCR overtemperature		
35	Battery/clock		
36	Thermistor circuit		
47	Overpower		
48	Underpower		
56	Keypad disconnected		
57	Zero Speed Detect		
58	SCR Itsm		
59	Instantaneous overcurrent		
60	Rating Capacity		
70	Current Read Err L1		
71	Current Read Err L2		
72	Current Read Err L3		
73	Remove Mains Volts (mains voltage connected in run simulation)		
74	Motor Connection T1		
75	Motor Connection T2		
76	Motor Connection T3		
77	Firing Fail P1		
78	Firing Fail P2		
79	Firing Fail P3		
80	VZC Fail P1		
81	VZC Fail P2		
82	VZC Fail P3		
83	Low Control Volts		
84~96	Internal fault x. Contact your local supplier with the fault code (X).		

# 7 Profibus Diagnostic Telegram and Flag

The Profibus Card supports external diagnostics. The following telegram will be sent to the Master if the soft starter trips or if a parameter is changed at the soft starter.

Diagnostic Telegram Data Structure				
Byte 0	User diagnostic length (Always set = 3)			
Byte 1	Trip Code			
Byte 2	Changed parameter number			

#### **Profibus Trip Code**

When the soft starter trips, a diagnostic flag is set at the Master and the trip code is reported in Byte 1. When the soft starter is reset, the diagnostic flag and trip code data are reset = 0, provided the trip condition does not still exist (see *Trip Codes* on page 9).

## **Changed Parameter Number**

If a parameter is changed via the keypad, the affected parameter number is reported in Byte 2. When the Master reads or writes the changed parameter, Byte 2 is reset = 0. A changed parameter number does not set a diagnostic flag.

# 8 Profibus Freeze Mode

The Profibus Card supports Freeze Mode.

In Freeze Mode, inputs are only updated with new data from the soft starter when another Freeze action is carried out. An Un-Freeze action returns the device to normal operation.

# 9 Profibus Sync Mode

The Profibus Card supports Sync Mode.

In Sync Mode, commands to the soft starter are not processed until another Sync action is carried out. An Un-Sync action returns the device to normal operation.

# 10 Profibus Clear Mode

If the Master sends a global Clear command, the device will send a Quick Stop command to the soft starter.

# 11 Specifications

5-way male and unpluggable female connector (supplied)
1 to 125
EN 60947-4-2
Compliant with EU Directive 2011/65/EU
PROFIBUS · PROFINET



BENSHAW 615 Alpha Drive Pittsburgh, PA 15238 Phones: (412) 968-0100 Fax: (412) 968-5415

BENSHAW Canada 550 Bright Street Listowel, Ontario N4W 3W3 Phone: (519) 291-5112 Fax: (519) 291-2595

